RCA

Television User's Guide

Changing Entertainment. Again.

Weather and other hazard information brought to you by the National Oceanic and Atmospheric Administration (NOAA)

Important Information

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts. When servicing use only identical replacement parts.

Caution: To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

This symbol indicates important instructions accompanying the product.

This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

WARNING

To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

Refer to the identification/rating label located on the back panel of your product for its proper operating voltage.

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

Caution: Using video games or any external accessory with fixed images for extended periods of time can cause them to be permanently imprinted on the picture tube (or projection TV picture tubes). ALSO, some network/program logos, phone numbers, etc. may cause similar damage. This damage is not covered by your warranty.

Cable TV Installer: This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Product Registration

Please fill out the product registration card (packed separately) and return it immediately. For U.S. customers: Your RCA Consumer Electronics product may also be registered at www.rca.com/productregistration. Registering this product allows us to contact you if needed.

Product Information

Keep your sales receipt to obtain warranty parts and service and for proof of purchase. Attach it here and record the serial and model numbers. These numbers are located on the product.

Model No. _____ Serial No. _____ Purchase Date: _____

Dealer/Address/Phone: _____

Alert Guard™ Important Information

- The green READY light on the front panel of the TV is the main indicator that the Alert Guard system is receiving NWR broadcast information. If it's not lit, the Alert Guard system can't inform you of alerts. During poor reception conditions, the Alert Guard system might not inform you of alerts even if the green light is on.
- Generally, the Alert Guard system can fail to notify you of dangerous conditions for the following reasons:
  1. National Oceanic and Atmospheric Administration (NOAA) did not broadcast an alert. Certain criteria must be met for NOAA to issue an alert, and only certain events are reported by NOAA. While weather forecasting continues to improve, it is not perfectly accurate. For this reason, situations that might be dangerous to you may be unknown to NOAA.
  2. Power was lost to the TV during the time when an alert was broadcast. If power is lost for more than 15 seconds, the Alert Guard system will notify you that power was interrupted the next time the TV is turned on. Any alerts issued during a power failure won't be acknowledged by the Alert Guard system. Therefore, you might want to purchase a battery operated alert radio or have a battery powered radio available for listening when household power fails.
  3. Reception of the NOAA Weather Radio (NWR) was poor at the time an alert was broadcast. Since NOAA only broadcasts an alert once, momentary loss of reception can prevent alerts from being received.
  4. Options in the Alert Guard menu, such as locations and the NWR channel, were not set appropriately. Instructions within the User's Guide will help you set up Alert Guard correctly.
- Alert Guard shouldn't be your only source of information. You should always maintain personal, family, and neighborhood safeguard systems, and remain aware of changing conditions. The Alert Guard system relays alerts based on information provided by the NWR. The Alert Guard system is designed to recognize all alerts currently issued over the all hazards NWR broadcast system. Incidents (such as local traffic accidents and weather related school closings) that don't endanger the community with immediate threats are not broadcast.
- Alert Guard coverage is limited to the U.S., U.S. territories, possessions and associated states, within your local geographic area. These areas are listed on pages 37-54.
- While it appears you can set up the Alert Guard system to receive alerts from across the country, it can only receive alerts broadcast for areas close to the location of the TV.
- For models 20F670T, 27V570T and 27F670T, don't leave headphones plugged in when they aren't in use. Alarms will sound through the headphones and not the TV's speakers, causing alarms not to be heard.
- If your TV is connected to a receiver, amplifier, home theater system, or other audio equipment, alerts won't be audible through such devices connected to the audio output terminals of the TV; instead, the Alert Guard system will turn on the TV's internal speakers to sound an alarm and make the alerts audible.
- Non-weather emergency messages, such as chemical spills, nuclear power plant emergencies, gas line breaks, etc., are not fully implemented nationally.
- If you receive an alert that tells you to seek shelter, do so immediately and don't continue to listen for other alerts until you are safe.
- It might take time, and after you've received several alerts, before you understand how the Alert Guard feature works.
- While government agencies use sophisticated equipment, such as weather models, radars, and satellites to determine an alert's effective time and duration, the end of an alert also does not necessarily mean that related emergency events are over. Weather conditions can change rapidly, and caution should be taken before and after alerts.

Alert Guard is a trademark of Thomson Inc.

Chapter 1: Connections & Setup

Things to Consider Before You Connect **3**
Protect Against Power Surges 3
Protect Components from Overheating 3
Position Cables Properly to Avoid Audio Interference 3
Important Stand and Base Safety Information 3
Use Indirect Light 3
Cables Needed to Connect Components to Your TV 3
Alert Guard Antenna 3
TV + DVD + VCR **4**
Explanation of Jacks **5**
The Front of Your TV **6**
Alert Guard Front Panel Buttons and Lights 6
Front Input Jacks 7
Front Panel Buttons 7
Connect Alert Guard Antenna **8**
Connect TV Antenna **8**
Plug in the TV **8**
Put batteries in the remote **8**
How to Use the Remote Control to Complete the Initial Setup **8**
Turn on the TV **9**
Complete the Initial Setup **9**
Complete Auto Channel Search 9
Alert Guard Initial Setup 9

Chapter 2: Using the Remote Control

Button Descriptions for TV Mode **11**
Button Descriptions for Alert Guard **11**
Button Descriptions for Other Modes **12**
Using the INPUT Button 12
Programming the Remote to Operate Other Components **13**
Find Out If You Need to Program the Remote 13
Programming the Remote 13
How to Use the Remote After You've Programmed It 14
Remote Control Codes **15**

Chapter 3: Using the TV's Features

Alert Guard **18**
Alert Options 19
Locations 20
News Weather 21
NWR Channel 21
Channel Banner **22**
Why You Should Use the Auto Tuning Feature **22**
How to Set Up the Auto Tuning Feature 22
Parental Controls and V-Chip **24**
How V-Chip Works 24
USA V-Chip Rating System 24
USA V-Chip TV Rating Limit 25
Blocking Specific Content Themes 26
Viewing Specific Content Themes 27
V-Chip Movie Rating Limit 27
V-Chip Exempt Program Block 27
KidPass 28
V-Chip Active 28
Front Panel Lock 28
Change Password 28

Chapter 4: Using the TV's Menu System

Sound Menu **29**
Picture Menu **30**
Setup Menu **31**
Parental Control Menu **32**
Time Menu **32**
Alert Guard Menu **32**

Chapter 5: Other Information

Troubleshooting **33**
Care and Cleaning **36**
Alert Guard Location Codes **37**
Limited Warranty (for models 20F670T, 27F670T and 32F670T) **55**
Limited Warranty (for model 27V570T) **57**

Things to Consider Before You Connect

Protect Against Power Surges

- Connect all components before you plug any of their power cords into the wall outlet.
- Turn off the TV and/or component before you connect or disconnect any cables.
- Make sure all antennas and cables are properly grounded. Refer to the Important Safety Instructions packed separately.

Protect Components from Overheating

- Don't block ventilation holes on any of the components. Arrange the components so that air can circulate freely.
- Don't stack components.
- If you place components in a stand, make sure you allow adequate ventilation.
- If you connect an audio receiver or amplifier, place it on the top shelf so the heated air from it won't flow around other components.

Position Cables Properly to Avoid Audio Interference

- Insert each cable firmly into the designated jack.
- If you place components above the TV, route all cables down the side of the back of the TV instead of straight down the middle of the TV.
- If your antenna uses 300-ohm twin lead cables, do not coil the cables. Also, keep the twin lead cables away from audio/video cables.

Important Stand and Base Safety Information

Choose the location for your TV carefully. Place the TV on a stand or base that is of adequate size and strength to prevent the TV from being accidentally tipped over, pushed off, or pulled off. This could cause personal injury and/or damage the TV. Refer to the Important Safety Instructions packed separately.

Use Indirect Light

Don't place the TV where sunlight or room lighting will be directed toward the screen. Use soft or indirect lighting.

Cables Needed to Connect Components to Your TV

The pictures below show the cables needed for the connection represented in this book.


Coaxial cable


S-Video cable


Audio/Video cables


Component Video (Y, Pb, Pr) cables

Alert Guard Antenna

Alert Guard Antenna

The picture to the left shows the Alert Guard antenna packed with your TV, specifically designed for the Alert Guard feature. Connect the antenna to the EXT Alert Guard ANT jack on the back of the TV (go to page 8 for more information). Don't connect the antenna to the regular TV ANT jack on the back of the TV.



* If you connect an S-Video cable, you must connect the audio cables to the VIDEO 1 AUDIO jacks on the back of the TV, **not** the VIDEO 2 AUDIO jacks.

TV + DVD + VCR

1. **Connect your DVD Player to your TV.**
   A. Connect the audio (white and red) cables to the VIDEO 2 R and L/MONO AUDIO jacks on the back of the TV and to the Audio Output jacks on the DVD player.
   B. If your DVD player has Component Output Jacks (Y, Pb, Pr), connect three video grade cables to the Y, Pb, Pr jacks on the DVD player and to the VIDEO 2 Y, Pb, Pr jacks on the back of the TV. If your DVD player doesn't have Y, Pb, Pr jacks, go to C.

   -OR-

   C. If your DVD player has an S-Video Jack, connect an S-Video cable to the S-Video jack on the DVD player and to the S-VIDEO IN jack on the back of the TV. If your DVD player doesn't have an S-Video jack, go to D.

   Note: If you connect an S-Video cable, you must connect the audio cables to the VIDEO 1 AUDIO jacks on the back of the TV, not the VIDEO 2 AUDIO jacks.

   -OR-

   D. Connect a video cable (yellow) to the Video Output Jack on the DVD player and to the VIDEO 2 VIDEO jack on the back of the TV.
2. **Connect your TV to your VCR.**

   Connect a coaxial cable to the TV ANT jack on your TV and to the Antenna Output Jack on your VCR (sometimes labeled OUT TO TV).

   Note: If your VCR has Audio/Video output jacks, you can connect your TV to your VCR using audio/video cables for better quality.
3. **Make sure cable or antenna is connected to your VCR.**

   Connect the coaxial cable from your cable outlet or antenna to the Antenna Input Jack (sometimes labeled IN FROM ANT) on the VCR.

Go to page 8

Explanation of Jacks

This section describes the jacks you can use to make connections. There are several ways to connect components to your TV.

TV ANT Lets you connect a coaxial cable to receive the signal from the antenna, cable, cable box, or if using the example on page 4, a VCR.

EXT Alert Guard ANT Lets you connect an antenna if you need to receive a stronger signal for the Alert Guard feature. Go to page 8 for more information.

VIDEO 1

VIDEO, AUDIO R and L/MONO INPUTS Lets you connect a component such as a VCR, DVD player, or laserdisc player.

- **R (RIGHT) AUDIO** Provides right audio connection. The right audio connector is usually red.
- **L/MONO AUDIO** Provides left audio connection. The left audio connector is usually white.
- **VIDEO** Provides composite video connection. The video connector is usually yellow.
- **S-VIDEO** Provides better picture quality than the composite video jacks because the color part of the signal is separated from the black and white part of the picture. When using S-VIDEO IN, make sure to also connect left and right audio cables to the VIDEO1 AUDIO Input jacks.



VIDEO 2

VIDEO, AUDIO R and L/MONO and Y, Pb, Pr INPUTS Lets you connect a component video source, such as a DVD player.

- **Y, Pb, Pr** Provides optimum picture quality because the video is separated into three signals. Use three video-grade cables for the connection. When using VIDEO 2 Y, Pb, Pr, make sure to also connect left and right audio cables to the VIDEO 2 AUDIO Input jacks.
- **R and L/MONO AUDIO and VIDEO** Their description is the same as VIDEO 1 above.



VIDEO 3

R and L AUDIO and Y, Pb, Pr INPUTS Lets you connect a second component video source, such as a DVD player. Their description is the same as VIDEO 2 above. When using VIDEO 3 Y, Pb, Pr, make sure to also connect the left and right audio cables to the VIDEO 3 AUDIO Input jacks.



AUDIO/VIDEO OUTPUTS (Video Out not available on model 27V570T) Lets you connect an amplifier or audio receiver for improved sound quality or an external video monitor, for models with Video Out.

The Front of Your TV

Alert Guard Front Panel Buttons and Lights

READY (Green Light) Remains lit as long as the TV is receiving a strong signal.

ADVISORY (Yellow light) On during Advisory alert. Also, lights for approximately 15 minutes during the weekly NOAA (National Oceanic and Atmospheric Administration) Weather Radio (NWR) test.

WATCH (Orange light) On during Watch alert.

WARNING (Red light) On during Warning alert.

Note: The lights blink when an alert is first received. To stop them from blinking, press STOP ALARM. Lights stay on until an alert has expired. For your protection, you can never turn a light off while an alert is in effect.

VIEW MESSAGE Press the VIEW MESSAGE button to display the alert being issued. If the TV is off, pressing this button turns on the TV and displays the message. Press this button at any time during an alert or weekly test to display the time remaining until the alert or test expires.

HEAR VOICE Toggles the NWR on and off.

STOP ALARM Turns off alarms and then removes on-screen messages.



27V570T Front Panel



20F670T, 27F670T, 32F670T Front Panel



Front Input Jacks

The TV has front input jacks for your convenience: one set of audio/video inputs, an S-Video and a headphone jack. These jacks are towards the front of the TV on the side. To access the component you connected to the front of the TV, press the INPUT button on your remote until *FRNT* (*SFRNT* for S-VIDEO) appears on the screen. The jacks are ideal for connecting a video game console or a camcorder.

Note: When connecting a component that only has one audio jack, such as some camcorders, use the TV's AUDIO L/MONO jack to hear the audio.

H-PHONE (Headphones- not available on model 32F670T) Allows you to connect headphones to listen to the sound coming from the TV.

Note: For models 20F670T, 27V570T and 27F670T, don't leave headphones plugged in when they aren't in use. Alarms will sound through the headphones and not the TV's speakers, causing alarms not to be heard.

VIDEO Receives video from another component such as a VCR, camcorder, or video game console.

L/MONO and RIGHT AUDIO Receives audio from another component such as a VCR, camcorder, or video game console.

S-VIDEO Allows you to connect an S-Video cable from another component. Make sure you also connect audio cables from the component to the TV.



Front Panel Buttons

If you can't locate your remote, you can use the front panel buttons of your TV to operate many of the TV's features.

MENU/OK Brings up the Main menu. In the menu system, it selects highlighted items.

CH v Scans down through the current channel list. In the menu system, acts like the down arrow button on the remote control and adjusts menu controls.

CH ∧ Scans up through the channel list. In the menu system, acts like the up arrow button on the remote control and adjusts menu controls.

VOL < Decreases the volume. In the menu system, acts like the left arrow button on the remote control and adjusts menu controls.

VOL > Increases the volume. In the menu system, acts like the right arrow button on the remote control and adjusts menu controls.

POWER Turns the TV on and off.



Connect Alert Guard Antenna

Connect the supplied antenna, with the rod positioned straight up and down, to the EXT Alert Guard ANT jack on the back of the TV.

Connect TV Antenna

If you haven't already, connect the coaxial cable from your cable source (if using the example on page 4, a VCR) to the TV ANT jack on the back of the TV.

Plug in the TV

Plug the end of the power cord into a grounded wall outlet. Insert the plug completely into the outlet.



Put batteries in the remote

- Remove the battery compartment cover from the back of the remote by pushing down on and sliding off the cover.
- Insert 2 fresh "AA" batteries. Make sure the polarities (+ and -) are aligned correctly.
- Replace the cover.



How to Use the Remote Control to Complete the Initial Setup

The technical term is "Navigation"– how you move through the on-screen menus. The method is the same throughout the menu screens: highlight your choice and select it.

To highlight a menu item, press the arrow buttons on the remote to highlight one of the items listed on the screen. Use the up or down arrow button to move up or down. Use the right or left arrow button to move right or left.

To select the item that you've highlighted, press OK.

Note: Highlighted means that the menu item stands out from other menu items on the list (appears darker, brighter, or a different color).

Turn on the TV

Press TV on the remote, or press POWER on the TV's front panel.

Note: Pressing the TV button not only turns on the TV, but puts the remote into TV mode. "TV mode" means that the buttons on the remote control operate the TV's functions.



Complete the Initial Setup

The menu system in your TV allows the TV's features to work properly. The first time you turn on your TV, the *SETUP* screen appears with *Language* highlighted. The default language is *English*. To choose another language, press the right arrow button.



Complete Auto Channel Search

This part of the setup allows the TV to search for all channels viewable through your antenna or cable TV system. This is sometimes called auto programming.

1. Highlight *Auto Ch. Search* and press OK.
2. The *Signal Type* option is set to *Cable*. To change the option to *Antenna*, press the right arrow button.
3. Press the down arrow button to highlight *Start*. Press the OK button to begin the auto channel search.

Once the search is complete, the *Alert Guard Setup* menu appears.

Alert Guard Initial Setup

Alert Guard informs you of hazards such as winter storm watches and civil danger warnings that are being broadcast by the all hazards NWR broadcast system for your specific area.

Note: Alert Guard receives alerts for the U.S. , U.S. territories, possessions and associated states, within your local geographic area. Your TV can't respond to alerts outside these areas. These areas are listed on pages 37-54.

Also, Alert Guard can only receive alerts broadcast for areas close to the location of the TV.



1. The quickest way to set your area is to highlight *Pick from list* and press OK. (If you want to set up Alert Guard by phone, highlight *Call a number*, call 1-888-NWR-SAME, and follow the on-screen instructions).

(steps continued on the next page)



2. The *PICK FROM LIST* menu appears with *All of U.S.* highlighted. Press the left or right arrow button to choose your region- the state, territory, or marine area where you are living or District of Columbia. These are listed in alphabetical order, with marine areas at the end of the list (press the left arrow button to access these quickly, starting at the end of the list).



3. After you set your region, press the down arrow button to highlight *All nearby*. Press the left or right arrow button to choose the county, city, parish, area, borough, district, island, atoll, state or municipality where you are living. These are also listed in alphabetical order. Most states only have counties as a choice.

The location code is now set. Highlight and select *Continue*. Alert Guard is ready to receive information specific to your area.



If you receive an on-screen message, *YOU MIGHT MISS ALERTS!,* press OK to tune to the strongest NWR channel. The *NWR channel* menu appears and searches for a strong channel.

Listen to the NWR channel. If the signal is clearly understandable and is broadcasting information for your local area, press CLEAR. *Alert Guard is set up* appears on-screen. Press CLEAR again to watch TV. If the signal isn't understandable or isn't broadcasting information for your local area, go to page 33 for more information.

You can set each alert level, Warning, Watch or Advisory, to notify you of alerts broadcasted by receiving a message on-screen or hearing a type of alarm. The default settings for these alert levels are:

	Warning	Watch	Advisory
Message on-screen	Yes	Yes	No (box not checked)
Alarm setting	Voice	None	None

To change these setting and for more information on how to customize options in Alert Guard, go to Chapter 3.

Note: If you move from the area you set in the Initial Setup, you need to set your new area in the Alert Guard LOCATIONS menu.



Button Descriptions for TV Mode

Arrows Used to point to different items in the TV menu and to adjust the menu controls.

Indicator Indicates the programming mode when programming the remote to control components. Lights when you press a valid button on the remote.

(0-9) Number Buttons Enter channel numbers and time settings directly through the remote control.

To enter a one-digit channel, enter a zero first. To enter a two-digit channel, press the two digits and expect a few seconds delay. This is in case you want to enter a third digit.

CH + or CH - Scans up or down through the current channel list. Press once to change the channel up or down; press and hold to continue changing channels.

CLEAR Removes any menu or display from the screen and returns you to normal viewing.

GO BACK Returns you to the previous channel.

INFO Brings up channel banner; press again to clear the screen.

INPUT Toggles through the available input sources (VID1/SVID1, VID2/CVID2, FRNT/SFRNT, CVID3 and current channel).

MENU Brings up the Main menu.

MUTE Reduces the TV's volume to its minimum level. Press again to restore the volume.

OK When in the menu system, selects highlighted items.

ON•OFF When in TV mode, turns the TV on and off. If in another mode (VCR, DVD, SAT•CABLE, etc.), will turn the component on and off.

SKIP Press once before changing channels and the TV will go back to the original channel after 30 seconds. Press repeatedly to add more time.

SOUND Displays the *SOUND* menu.

TV Turns on the TV and puts the remote in TV mode. Also displays current status.

VOL – or VOL + Decreases or increases the TV's volume.

Button Descriptions for Alert Guard

(Listed from left to right)

VIEW MESSAGE Press to display the alert being issued. If the TV is off, pressing this button turns on the TV and displays the message. Press this button at any time during an alert or weekly test to display the time remaining until the alert or test expires.

HEAR VOICE Toggles the NWR on and off.

STOP ALARM Turns off alarms and then removes on-screen messages.

NEWS WEATHER Scans through the four channels in the order they were set in the News Weather menu. If no channels have been set up, the default News Weather station is channel 6. If the TV is off, pressing this button turns the TV on and tunes to the first News Weather channel.

Button Descriptions for Other Modes

AUX Puts the remote in AUX mode. Can also be programmed to operate most brands of an additional remote-controllable component.

ANTENNA In VCR mode, functions as a TV/VCR button. In SAT•CABLE mode, functions as a TV/receiver button.

DVD Puts the remote in DVD mode and, if auto tuning is enabled, will turn on the TV and tune to the correct video input channel.

GUIDE If you're operating another component that has an on-screen program guide, this button accesses the on-screen guide.

REVERSE, PLAY, FORWARD, RECORD, STOP, PAUSE If programmed, provides transport control for some remote-controllable VCRs, DVD players, and CD players.

SAT•CABLE Puts the remote in SAT•CABLE mode and, if auto tuning is enabled, will turn on the TV and tune to the correct video input channel.

VCR1 Puts the remote in VCR mode and, if auto tuning is enabled, will turn on the TV and tune to the correct video input channel.

VCR2 Puts the remote in VCR mode to operate a second VCR and, if auto tuning is enabled, will turn on the TV and tune to the correct video input channel.

Using the INPUT Button

Use the INPUT button to scroll through the available video input channels and view components you have connected to the TV.

1. Press TV to place the remote in TV mode. Make sure the component you want to view is turned ON.
2. Press INPUT to tune to an available video input source and view the component.
3. To return to the previous channel, continue pressing INPUT.



You'll use these buttons when programming the remote.

Programming the Remote to Operate Other Components

The universal remote can be programmed to operate most brands of remote controllable components. The remote is already programmed to operate most RCA, GE, and Proscan components.

Also, the AUX button can be programmed to operate most brands of an additional remote-controllable component.

Notes: The TV button can't be programmed on this remote.

The remote may not be compatible with all brands and models of components. It also may not operate all functions of the remote that came with your component.

Find Out If You Need to Program the Remote

To determine whether the universal remote needs to be programmed for your component, turn the component ON. For example, to program the remote for a VCR, turn on the VCR. Point the remote at the VCR, and press the VCR1 button. Then press ON•OFF or CH + (channel up) or CH – (channel down) to see if the VCR responds to the remote commands. If the component does not respond, the remote needs to be programmed.

Programming the Remote

There are two ways to program the remote control:

- automatic code search
- direct entry

Using Automatic Code Search

The following instructions can be used to program the remote to operate each of your components. If you want to stop the automatic code search without programming any of your components, press CLEAR until the indicator on the remote turns off.

1. Turn on the component you want to operate (VCR, DVD player, etc.)
2. Press and hold the component button you want to program (VCR1, DVD, etc.). While holding the component button, press and hold ON•OFF until the indicator on the remote turns on, then release both buttons.
3. Point the remote at the component. Press and release PLAY, then wait 5 seconds or until the indicator on the remote stops flashing.

   At this point the remote is searching for the correct code to program. If, after 5 seconds, the component you want to operate does not turn off, press PLAY again to tell the remote to search the next set of codes.

   Continue pressing PLAY until the component turns off or you have searched through all of the codes. There are 20 total sets of codes. If the component does not turn off after pressing PLAY 20 times, then the remote can't be programmed to operate that component. Press CLEAR to turn off the indicator light.

If the component you want to control *does* turn off:

1. Press and release REVERSE, then wait 2 seconds. Repeat this step until the component turns back ON.
2. To finish, press and hold STOP until the indicator on the remote turns off.

Using Direct Entry

1. Turn on the component to be programmed.
2. Look up the brand and code number(s) for the component on the code list in this section.
3. Press and hold the component button you want to program on the remote.
4. Enter the 4-digit code from the remote control code list on the following pages. If the indicator flashes, you have either entered an invalid code or the button isn't programmable.
5. Release the component button.
6. Point the remote at the component. Press ON•OFF to see if the component responds to the command. If it doesn't, try pressing the component button and then ON•OFF again.

- If you get no response, repeat these steps using the next code listed for your brand, until the component responds to the remote commands.
- If you try all the codes for your component brand and none work, try the automatic code search method. If automatic code search doesn't find the code, the remote is not compatible with your component.

How to Use the Remote After You've Programmed It

Because this universal remote can control several different components (TV, DVD, VCR, satellite receiver, etc.) it uses operational modes triggered by the component buttons. For example, if you want the remote to control the TV, you would press the TV button to put the remote into TV mode before you could control the TV.

1. Press the appropriate component button (DVD, TV, VCR1, VCR2, SAT•CABLE, AUX) to set the remote to control the component.
2. Press ON•OFF to turn the component ON or OFF.
3. Use the remote buttons that apply to that component.

Note: If you keep pressing buttons and nothing happens, the remote is probably in the wrong mode. You must press the component button that matches the component you want to operate (i.e., if you want to operate the VCR, press VCR1 on the remote control to put the remote in VCR mode.)

Remote Control Codes

VCR Codes

Programmable for VCR1, VCR2 and AUX buttons.

Admiral 2132
Adventura 2026
Aiko 2027
Aiwa 2026
Akai 2003, 2004, 2005, 2007, 2008, 2111, 2112, 2113
American High 2021
Asha 2013
Audio Dynamics 2009, 2010
Audiovox 2014
Bell & Howell 2011
Beaumark 2013
Broksonic 2012, 2025
Calix 2014
Candle 2013, 2014, 2015, 2016, 2017, 2018, 2019
Canon 2021, 2022, 2114
Capehart 2020, 2110
Carver 2062
CCE 2027, 2061
Citizen 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2027
Colortyme 2009
Colt 2061
Craig 2013, 2014, 2023, 2061
Curtis-Mathes 2000, 2009, 2013, 2016, 2018, 2021, 2022, 2024, 2115, 2131
Cybernex 2013
Daewoo 2015, 2017, 2019, 2025, 2026, 2027, 2028, 2110
Daytron 2110
DBX 2009, 2010
Dimensia 2000, 2131
Dynatech 2026
Electrohome 2014, 2029
Electrophonic 2014
Emerson 2012, 2014, 2015, 2021, 2024, 2025, 2026, 2029, 2030, 2031, 2032, 2033, 2034,2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042,2044, 2045, 2046, 2047, 2065, 2113, 2116, 2117, 2130
Fisher 2011, 2023, 2048, 2049, 2050, 2051, 2052, 2118
Fuji 2021, 2119
Funai 2026
Garrard 2026
GE 2000, 2001, 2013, 2021, 2022, 2053, 2115, 2120, 2131
Goldstar 2009, 2014, 2018, 2054
Gradiente 2026
Harley Davidson 2026
Harman Kardon 2009
Harwood 2061
Headquarter 2011
Hitachi 2055, 2056, 2057, 2107, 2111, 2120, 2122
Hi-Q 2023
Instant Replay 2021
JCL 2021
JC Penney 2009, 2010, 2011, 2013, 2014, 2021, 2022, 2055, 2056, 2058, 2059, 2060, 2107, 2118
Jensen 2055, 2056, 2111
JVC 2009, 2010, 2011, 2018, 2111, 2123
Kenwood 2009, 2010, 2011, 2016, 2018, 2111, 2123
KLH 2061
Kodak 2014, 2021
Lloyd 2026
Logik 2061
LXI 2014
Magnavox 2021, 2022, 2062, 2063, 2104, 2105, 2108, 2124
Magnin 2013
Marantz 2009, 2010, 2011, 2016, 2018, 2021, 2062, 2064
Marta 2014
Masushita 2021
Mei 2021
Memorex 2011, 2013, 2014, 2021, 2023, 2026, 2104, 2132
MGA 2029, 2065, 2113
MGN Technology 2013
Midland 2053
Minolta 2055, 2056, 2107
Mitsubishi 2029, 2055, 2056, 2065, 2066, 2067, 2068, 2068, 2070, 2071, 2072, 2073, 2074, 2106, 2113, 2123
Montgomery Ward 2075, 2132
Motorola 2021, 2132
MTC 2013, 2126
Multitech 2013, 2016, 2026, 2053, 2061
NEC 2009, 2010, 2011,2016, 2018, 2064, 2076, 2078, 2079, 2111, 2123
Nikko 2014
Noblex 2013
Olympus 2021
Optimus 2014, 2132
Optonica 2096
Panasonic 2021, 2022, 2109, 2125, 2126, 2127
Pentax 2016, 2055, 2056, 2107, 2120
Pentex Research 2018
Philco 2021, 2022, 2062, 2063
Philips 2021, 2062, 2096, 2124
Pilot 2014
Pioneer 2010, 2055, 2080, 2081, 2123
Portland 2016, 2017, 2019, 2110
Proscan 2000, 2001, 2131
Protec 2061
Pulsar 2104
Quarter 2011
Quartz 2011
Quasar 2021, 2022, 2125
RCA 2000, 2001, 2003, 2013, 2021, 2055, 2056, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2107, 2115, 2120, 2125, 2131, 2133
Radioshack/Realistic 2011, 2013, 2014, 2021, 2022, 2023, 2026, 2029, 2049, 2050, 2096, 2132
Radix 2014
Randex 2014
Ricoh 2128
Runco 2104
Samsung 2005, 2013, 2015, 2033, 2053, 2112
Sanky 2104, 2132
Sansui 2010, 2092, 2111, 2123
Sanyo 2011, 2013, 2023
Scott 2012, 2015, 2025, 2032, 2038, 2065, 2093, 2116
Sears 2011, 2014, 2021, 2023, 2048, 2049, 2050, 2051, 2055, 2056, 2107, 2118
Sharp 2017, 2029, 2094, 2095, 2096, 2097, 2132

VCR Codes continued

Shintom 2004, 2056, 2061, 2098
Shogun 2013
Signature 2132
Singer 2021, 2061, 2128
Sony 2004, 2098, 2099, 2119
STS 2021, 2107
Sylvania 2021, 2022, 2026, 2062, 2063, 2065, 2124
Symphonic 2026
Tandy 2011
Tashiko 2014
Tatung 2111
TEAC 2026, 2085, 2111
Technics 2021, 2109
Teknika 2014, 2021, 2026, 2100, 2129
TMK 2013, 2024, 2047
Toshiba 2015, 2049, 2051, 2055, 2065, 2093, 2116
Totevsion 2013, 2014
Unitech 2013
Vector Research 2009, 2010, 2015, 2016
Victor 2010
Video Concepts 2009, 2010, 2015, 2016, 2113
Videosonic 2013
Wards 2013, 2014, 2015, 2021,
..... 2023, 2026, 2029, 2055, 2056, 2061,
..... 2096, 2101, 2102, 2103, 2107, 2116, 2132
XR-1000 ..... 2021, 2026, 2061
Yamaha 2009, 2010, 2011, 2018, 2111
Zenith 2004, 2098, 2104, 2119, 2128

DVD codes

Programmable for DVD and AUX buttons.

Aiwa 3009
Apex 3023, 3024
GE 3000
Hitachi 3008
JVC 3002, 3010
Konka 3011, 3012
Magnavox 3003
Mitsubishi 3004
Panasonic 3013
Philips 3003, 3019, 3021, 3022
Pioneer 3005
Proscan 3000
RCA 3000, 3001
Samsung 3025
Sanyo 3014
Sony 3006, 3015, 3016
Toshiba 3007, 3017, 3020
Zenith 3018

Cable Box Codes

Programmable for SAT•CABLE and AUX buttons.

ABC 5002, 5003, 5004, 5005, 5006, 5053
Antronix 5008, 5009
Archer 5008, 5009, 5010
Cabletenna 5008
Cableview 5008
Colour Voice 5012, 5013
Comtronics 5014
Contec 5016
Eastern 5017
GC Electronics 5009
GE 5000, 5001
Gemini 5018, 5019
General Instrument 5003
Hamlin 5020, 5021, 5022, 5028, 5035, 5045
Hitachi 5003
Jerrold 5003, 5018, 5023, 5024, 5046, 5053
Magnavox 5025
Memorex 5026
Movie Time 5027
NEC 5005
NSC 5027
Oak 5016, 5029
Panasonic 5048, 5052
Philips 5011, 5012, 5013,5015, 5019,
5025, 5030, 5031, 5032
Pioneer 5033, 5034
Proscan 5000, 5001
RCA 5007, 5047, 5049, 5052
Realistic 5009
Regal 5022, 5035
Regency 5017
Rembrandt 5003
Samsung 5034
Scientific Atlanta 5006, 5036, 5037, 5038
Signal 5018
Signature 5003
Sprucer 5052
Standard Components 5039, 5044
Starcom 5018, 5053
Stargate 5018
Starquest 5018
Tandy 5040
Teleview 5014
Tocom 5004, 5023
Tusa 5018
TV86 5027
Unika 5008, 5009
United Cable 5053
Universal 5008, 5009, 5010
Viewstar 5025, 5027
Zenith 5050, 5051

Satellite Receiver Codes

Programmable for SAT•CABLE and AUX buttons.

Alphastar 5079
Chapparal 5056, 5057
Dishnet 5078
Drake 5058, 5059
Echostar 5089
GE 5000, 5001
General Instruments 5060, 5061, 5062
Hitachi 5083, 5084
Hughes 5077, 5090
JVC 5082
Panasonic 5075
Philips 5085
Primestar 5076
Proscan 5000, 5001
RCA 5000, 5001, 5071, 5080, 5081
Realistic 5063
Sony 5072
STS1 5064
STS2 5065

Satellite Receiver Codes continued

STS3 5066
STS4 5067
Toshiba 5068, 5073
Uniden 5086

Audio Codes

Programmable for the AUX button only.

RCA and Dimensia

AM/FM 4003, 4270
AUX 4004
Phono 4005
Tape 4006
CD 4007, 4190, 4211

Receivers

Aiwa 4261, 4262, 4263, 4264, 4265, 4266, 4267, 4277
Denon 4283
Harman Kardon 4276
JVC 4268
JVL 4276
Kenwood 4269
Onkyo 4278
Optimus 4284
Panasonic 4279, 4280
Pioneer 4275
RCA 4270
Sherwood 4282
Sony 4271, 4272, 4281
Technics 4279, 4280
Wards 4275
Yamaha 4274, 4275

CD Players

ADC 4200, 4201, 4220
Aiwa 4175, 4203
Akai 4205
Denon 4208
Dynatech 4177
Emerson 4178
Fisher 4179, 4212, 4213
GE 4216
Hitachi 4180
JVC 4181, 4221
Kenwood 4183, 4222, 4224
Luxman 4225
Marantz 4185, 4226
MCS 4228
Mitsubishi 4229, 4230
NEC 4184
Nakamichi 4232, 4233
Onkyo 4186, 4234, 4235
Optimus 4237, 4238, 4239
Panasonic 4188
Pioneer 4189, 4240
RCA 4190, 4211
Sanyo 4250
Sears 4207
Sherwood 4243
Sony 4195, 4209, 4244
Teac 4245, 4246, 4247
Technics 4197
Toshiba 4231
Yamaha 4198, 4199, 4248

Alert Guard

Alert Guard receives digital data known as SAME (Specific Area Message Encoding) combined with audio information provided by NOAA (National Oceanic and Atmospheric Administration) Weather Radio (NWR).

Note: For more information about NOAA, visit www.noaa.gov.

NOAA conducts a weekly test for the all hazards broadcast system. The test is once a week on Wednesday between 10 a.m. and 12 noon for approximately 15 minutes. The yellow ADVISORY light blinks during the test. If there is ongoing severe weather or a threat of severe weather, the test is postponed until the next available good-weather day. Alert Guard uses this test to ensure you've set the channel and locations properly. If Alert Guard detects a problem, on-screen messages appear to provide help.

The Alert Guard system receives alerts for the U.S., U.S. territories, possessions and associated states, within your local geographic area. Your TV can't receive any alerts for locations outside these areas. Also, if alerts are issued for areas other than those that you set in the *Location* menu, Alert Guard won't notify you of those alerts.

Alerts received by the Alert Guard system follow:

NOAA Natural and Weather Events- These include approximately 30 alerts, such as tornadoes, flash floods, avalanches, blizzards, forest fires, hurricanes, tsunamis, volcanoes, earthquakes, etc.

State and County Civil Emergency Alerts- The Alert Guard feature responds to current civil emergency alerts issued by all hazards NWR network. These include localized nuclear power plant emergencies, gas line breaks, train derailments, missing children alerts (America's Missing: Broadcast Emergency Response- AMBER Alerts), etc. These non-weather emergency messages are not fully implemented nationally.

National, Regional and State Civil Emergency Alerts- These include high level state or federal emergencies, such as national attack warnings, terrorist attack alerts (not alert level or threat condition status), bio-warfare alerts and other immediate life-threatening emergencies. This information is relayed by the Federal Emergency Management Agency (FEMA) and NOAA over the all hazards NWR network.

Alert Guard has several different levels of alerts. A list and explanation follows:

Warning- These alone pose a significant threat to public safety and/or property, probability of occurrence and location is high, and the onset time is relatively short.

Watch- Meets classification of a warning, but either the onset time, probability of occurrence, or location is uncertain.

Advisory- This event by itself might not kill, injure, or cause property damage but may indirectly cause other things to happen that result in a hazard.

A list of the type of alert levels you can receive follows on the next page.

Alerts			
Warning level		**Watch level**	**Advisory level**
Avalanche Warning	*Nuclear Power Plant Warning*	*Avalanche Watch*	*Administrative Message*
Blizzard Warning	*Practice/Demo Warning*	*Coastal Flood Watch*	*Child Abduction Emergency (AMBER alerts)*
Civil Danger Warning	*Radiological Hazard Warning*	*Flash Flood Watch*	*Emergency Action Termination*
Civil Emergency Message	*Severe Thunderstorm Warning*	*Flood Watch*	*Flash Flood Statement*
Coastal Flood Warning	*Shelter in Place Warning*	*High Wind Watch*	*Flood Statement*
Dust Storm Warning	*Special Marine Warning*	*Hurricane Watch*	*Hurricane Statement*
Earthquake Warning	*Tornado Warning*	*Severe Thunderstorm Watch*	*Local Area Emergency*
Emergency Action Notification	*Tropical Storm Warning*	*Tornado Watch*	*National Information Center Message*
Fire Warning	*Tsunami Warning*	*Tropical Storm Watch*	*Network Message Notification*
Flash Flood Warning	*Volcano Warning*	*Tsunami Watch*	*911 Telephone Outage Emergency*
Flood Warning	*Winter Storm Warning*	*Winter Storm Watch*	*Severe Weather Statement*
Hazardous Materials Warning			*Special Weather Statement*
High Wind Warning			
Hurricane Warning			
Immediate Evacuation			
Law Enforcement Warning			

Note: Alert messages provide only basic information. For example, if a Civil Emergency Message appears on-screen, you need to press HEAR VOICE to hear information about the specific alert it's covering, such as a train derailment, toxic gas leak, oil refinery fire, water supply pollution or an industrial explosion.





Alert Options

You can customize how you want to receive each alert level.

1. Press the MENU button (the *MAIN MENU* appears).
2. Press the down arrow button to highlight *Alert Guard* and press OK.
3. Select *Alert options* from the ALERT GUARD menu.
4. Press the right arrow button to highlight the alert level you want to customize, for example, *Advisory.*
5. Press the down arrow button to highlight *Message seen.* If you want an alert message to appear on-screen when receiving an Advisory, press the right arrow button until the *Message seen* box is checked.

Notes: Alert messages don't appear when the TV is off.

Alert messages provide only basic information. You might need to press HEAR VOICE to get more specific information.

(steps continued on the next page)

6. Press the down arrow button to highlight *Alarm type*. Press the right arrow button to highlight the type of alarm you want to hear when receiving an Advisory. If you don't want any alarm set, choose *None*.

   Notes: For models 20F670T, 27V570T and 27F670T, don't leave headphones plugged in when they aren't in use. Alarms will sound through the headphones and not the TV's speakers, causing alarms not to be heard.

   If your TV is connected to a receiver, amplifier, home theater system, or other audio equipment, alerts won't be audible through such devices connected to the audio output terminals of the TV; instead, the Alert Guard system will turn on the TV's internal speakers to sound an alarm and make the alerts audible.

7. If you set an Alarm type, press the down arrow button to highlight *Alarm volume*. Press the right or left arrow button to set the highest volume of the alarm. You might want to think of how loud the volume needs to be if you're somewhere else in your home . For example, if you want the alarm to wake you up while sleeping in the other room, then you might need to set the volume at the highest level.

   The Siren option is a loud sound, designed to get your attention. The Chime option is a subtle sound for those easily startled. When the Siren or Chime sounds, it starts soft and continues to get louder until it reaches the maximum volume you set. The Voice option is the voice of NWR which states the alert and then shuts off. The Voice option doesn't get louder. It speaks at the volume you set.

8. When finished, if you want to customize *Warning* or *Watch* level, press the up or down arrow button to highlight *Alert level.* Then follow steps 4-7.







Locations

You can receive alerts from three other locations within close proximity of where you live. To set these areas:

1. Press the MENU button (the *MAIN MENU* appears).
2. Press the down arrow button to highlight *Alert Guard* and press OK.
3. Select *Locations* from the ALERT GUARD menu.
4. Press the left or right arrow button to choose which area you want to set, for example *Nearby 1* (if you completed the Alert Guard initial setup, *My Area* has already been set). Set the areas in order of priority.
5. Press the down arrow button to highlight *No area.*
6. Press the right arrow button to highlight the state, territory, or marine area where you are living or District of Columbia. These are listed in alphabetical order, with marine areas at the end of the list (press the left arrow button to access these quickly).
7. Press the down arrow button to highlight *All nearby.*
8. Press the right arrow button to choose another area different than the area set for *My Area*. This could be another county, city, parish, area, borough, district, island, atoll, state or municipality nearby where you are living.

   The location code is now set. If you want to set another area, press the up arrow button to highlight *Location*. Press CLEAR to exit.

9. If you can't find your location, you need to set it manually. Press the down arrow button to highlight *Location code*.
10. Go to pages 37-54 or call toll-free 1-800-NWR-SAME to find the location code for your area. Enter the code using the number buttons on the remote.

Note: Occasionally the government changes or adds location codes. If you live in a new county or renamed county, you need to call 1-800-NWR-SAME because the code probably isn't in the list. Enter the code using the number buttons on the remote. Question marks (???) will appear in the area above the location code, which is normal since the TV isn't aware of this new area. Alert Guard will still respond if an alert is received for this location.



News Weather

You can set up to four different news or weather channels which correspond to the NEWS WEATHER button on the remote.

The default for Choice 1 is channel 6. To set a different channel:

1. Press the down arrow button to highlight *Choice 1*.
2. Press the left or right arrow button to choose the first news weather channel. You can also use the number buttons to enter the channel, for example, channel 12. Press number 1, then 2, and then press OK.
3. To set the other news weather choices, follow the same steps.

Each time you press the NEWS WEATHER button, the TV toggles through the choices in the order they were set.



NWR Channel

Alert Guard can search for the strongest NWR channel to use in order to receive an alert. If your TV is having trouble receiving a channel, you might need to search again for the NWR channel.

1. Select *NWR channel* from the ALERT GUARD menu.
2. Press the down arrow button to highlight *Start search*.
3. Press the OK button to begin the channel search. The TV searches through channels 1-7 to find the strongest reception.

Notes: You might want to search manually for the best channel. The best channel is one that broadcasts information for your local area and is clearly understandable. Highlight NWR channel and press the left or right arrow button to select a channel.

The NWR channel and location work together. A transmitter serves specific counties, cities, etc., nearby. It might be necessary to select a different channel or locations. If Alert Guard detects a problem, on-screen messages appear to provide help.

Channel	Frequency (MHz)
1	162.400
2	162.425
3	162.450
4	162.475
5	162.500
6	162.525
7	162.550



Channel Banner

There are several items that might appear when you press the TV or INFO button on the remote. This display is called the Channel Banner. The following list describes the items on the Channel Banner screen (left to right and top to bottom).

SAP	Displayed when the current channel is broadcasting SAP (Second Audio Program) information.
✓	Displayed when V-Chip has been activated.
KidPass: 2:24	Displayed when KidPass is set and the length of time remaining.
CC	Displayed when Closed Captioning is available on the current channel.
Stereo or *Mono*	Stereo displayed when the current channel is broadcasting in stereo.
	Mono displayed when the current channel is broadcasting in mono.
Skip: 0:30	Corresponds to the SKIP button. Shows the amount of time left before the TV switches back to the previous channel.
07:18 am	Displays the current time.
06 ABCDEF	Displays the current channel and label assigned to the channel.
🔇X	Displayed when you mute the sound.

Why You Should Use the Auto Tuning Feature

The auto tuning feature automatically tunes the TV to the correct channel for different components you have connected to your TV (like a VCR, DVD Player, etc.) When you set up auto tuning in the menu system, you don't have to remember to change your TV to channel 3; for example, when you want to watch the tape in your VCR.

How to Set Up the Auto Tuning Feature

The way you set up the auto tuning feature in the TV's menu corresponds to the component buttons on the remote and the way you have each component connected to your TV. When you set up auto tuning, you're telling the TV what channel to tune to when you press the VCR1, VCR2, DVD, or SAT•CABLE button on the remote control.

1. Press MENU (the *MAIN MENU* appears).
2. Highlight *Setup* and press OK on your remote control.
3. Highlight *Auto Tuning* and press OK.

4. Choose which channel you would like to set:
   Set VCR1 The channel the TV tunes to when you press the VCR1 button.
   Set VCR2 The channel the TV tunes to when you press the VCR2 button.
   Set SAT/CABLE The channel the TV tunes to when you press the SAT•CABLE button.
   Set DVD The channel the TV tunes to when you press the DVD button.
5. Press the right arrow button to select the choice that matches the way you have the component connected to this TV, and press OK.

The choices and a brief explanation follow:



N/A Choose this if you don't have this particular component connected to the TV, or if you don't want the TV to automatically tune to the correct channel when you're using this component.

CH02 **(SAT/CABLE only)** Component is connected to the TV ANT jack on the back of the TV, and you want the TV to tune to channel 2 when you press the SAT•CABLE button on the remote. Reminder: make sure the component's Channel 2/3/4 switch is set to channel 2. Usually this switch is on the back of the component.

CH03 or 04 Component is connected to the TV ANT jack on the back of the TV, and you want the TV to tune to channel 3 or 4 when you press the corresponding button on the remote. Reminder: make sure the component's Channel 3/4 switch is set to the appropriate channel.

VID1 Component is connected to the VIDEO 1 VIDEO or S-VIDEO jack on the back of the TV and you want the TV to tune to a video input channel when you press the corresponding button.

VID2 Component is connected to the VIDEO 2 VIDEO or Y, Pb, Pr jacks on the back of the TV and you want the TV to tune to a video or component video input channel when you press the corresponding button.

VID3 Compatible component video source, such as a DVD player or digital TV converter box, is connected to the VIDEO 3 Y, Pb, Pr jacks on the back of the TV and you want the TV to tune to the component video input channel when you press the corresponding button.

FRNT (Front Video Input) Component is connected to the VIDEO or S-VIDEO jack on the front of the TV and you want the TV to tune to the front video input channel when you press the corresponding button.

Parental Controls and V-Chip

The choices in the *USA V-CHIP* menu involve software inside your TV (referred to as V-Chip) which allows you to block TV programs and movies based on violence, sex, or other content you may believe children should not view.

Once you block programs, you can unblock programs by entering a password.

By default, the software inside your TV is turned "off." For instructions to turn on V-Chip, go to page 28.

How V-Chip Works

V-Chip reads the program's age-based rating (TV-MA, TV-14, etc.) and content themes [(Violence (V), Adult Language (L), etc.)]. If you have blocked the rating and/or content themes that the program contains, you will receive the message *This channel has not been approved for viewing. Change channel or press OK to enter password and temporarily deactivate the Parental Control.*

Broadcasters are not required to provide content themes, so programs received with no content themes will only be blocked if you block their age-based rating. You can also block out programs that have been given a rating of Not Rated, and programs that are considered unrated. The TV age-based ratings and content themes you can block follow:

USA V-Chip Rating System

TV-MA (Mature Audience Only) Specifically designed to be viewed by adults and may be unsuitable for children under 17. It contains one or more of the following content themes: crude indecent language (L), explicit sexual activity (S), or graphic violence (V).

TV-14 (Parents Strongly Cautioned) Contains some material that many parents would find unsuitable for children under 14. Parents are strongly urged to exercise greater care in monitoring this program and are cautioned against letting children under the age of 14 watch unattended. This program contains one or more of the following content themes: intensely suggestive dialogue (D), strong coarse language (L), intense sexual situations (S), or intense violence (V).

TV-PG (Parental Guidance Suggested) Contains material that parents may find unsuitable for younger children. Many parents may want to watch it with their younger children. The program contains one or more of the following content themes: some suggestive dialogue (D), infrequent coarse language (L), some sexual situations (S), or moderate violence (V).

TV-G (General Audience) Most parents would find this program suitable for all ages. It contains little or no sexual dialogue (D) or situations (S), no strong language (L), and little or no violence (V).

TV-Y7 (Directed to Children 7 years and older) Designed for children ages 7 and above. It may be more appropriate for children who have acquired the developmental skills needed to distinguish between make-believe and reality. Themes and elements in this program may include mild fantasy violence (FV) or comedic violence, or may frighten children under the age of 7.

TV-Y (All Children) Themes and elements in this program are designed for a young audience, including children from ages 2-6. It is not expected to frighten younger children.



USA V-Chip TV Rating Limit

The V-Chip TV Rating Limit lets you decide which TV programs can and cannot be viewed.
To set TV programming limits:

1. Choose *Parental Control* from the MAIN MENU (the *PASSWORD* screen appears the first time you enter the *Parental Control* menu). Create your password using the number buttons on the remote.
2. Highlight and select *USA V-Chip*. Then select *TV Ratings*.
3. Once you get to the *TV RATING LIMIT* screen, use the arrow buttons and OK on your remote to change the status of a TV program rating or content theme from *View* to *Block*.
4. For TV rating limits to take effect, turn *on V-Chip active* in the *PARENTAL CONTROL* menu (box has check mark).

The following sections give you more details about how to change the status of TV program limits.

Note: If you forget your password you can reset it. Make sure the TV is off. Simultaneously press and hold VOL< on the TV's front panel and CLEAR on the remote for approximately 5 seconds. Enter a new password the next time you access the PARENTAL CONTROL menu.

The V-Chip Rating Screen

The following is an example of where items are located within the Rating Limit screen.

Rating Status Field
Lets you select whether the status of the age-based rating limit to the left is View or Block.



Content Themes
Lists the content themes you can block or view.

Rating Field
Lets you select from a list of age-based ratings you can block or view.

Content Status Fields
Lets you select which content themes to view for the selected rating, and whether the status of the content theme is currently View (V) or Block (B).

Rating Settings Area
Lets you see the current block/view state of age-based ratings and associated content.

Hierarchy of Age-Based Ratings	
TV-MA	*Mature Audience Only*
TV-14	*Parents Strongly Cautioned*
TV-PG	*Parental Guidance Suggested*
TV-G	*General Audience*
TV-Y7	*Directed to Children 7 years and older*
TV-Y	*All Children*

Blocking Age-Based Ratings

You can automatically block all program ratings above a specified age-based rating level.

To block programs with higher ratings:

1. Press the up or down arrow button to scroll to the rating corresponding with the lowest rating you don't want the child to watch.
2. Press the OK button to toggle between *View* and *Block*. The status for the rating listed to the left and all higher ratings automatically changes to *Block*.
3. Press the up or down arrow button to highlight *Go back* and press OK.
4. Turn on *V-Chip active* in the *PARENTAL CONTROL* menu (box has check mark) for rating limits to take effect.

Viewing Age-Based Ratings

After you block age-based ratings, you can change some of the ratings back to *View*.

1. Press the up or down arrow button to select the rating with a status of *Block*.
2. Press OK to select *View*.

Content Themes	
D	*Sexually explicit dialogue*
L	*Adult language*
S	*Sexual situations*
V	*Violence*
FV	*Fantasy Violence*



Blocking Specific Content Themes

You can block programs based on their content. (Content is represented by the D, L, S, V and FV on your screen.) When you block a content theme for a particular rating, you automatically block that content theme for higher rated programs as well.

To block program content:

1. Determine the content themes you want to block.
2. Press the down arrow button to scroll to the rating whose content theme you want to change.
3. Press the right arrow button to move the highlight to a particular content theme status.
4. Press the OK button to change its status to *B*. (In the example to the left, you block the language (L) corresponding with TV-14. The language for TV-MA is blocked as well).

Notes: Broadcasters are not required to provide content themes or age-based ratings.

You must remember to activate Parental Controls for rating limits to take effect.

Viewing Specific Content Themes

If you block specific content themes, you have the option of going back and changing some of the content themes back to *(V) View*:

1. Determine the content themes you want to change to *(V) View*.
2. Press the down arrow button to scroll to the rating whose content theme you want to change, such as *B* under language (L) corresponding with TV-14.
3. Press the right arrow button to move the highlight to a particular content theme status.
4. Press the OK button to change the status back to *V*. Your child would then be able to watch programs with the TV-14 adult language content, but not programs with TV-MA language content.

Note: Only the content theme status corresponding to TV-14 (L) language changes to (V) View. Higher rated content themes, such as that for TV-MA language, do not change.

V-Chip Movie Rating Limit

Set movie rating limits by blocking movies rated above a specified level.

To access the Movie Rating menu:

1. Press MENU on the remote control (the *MAIN MENU* appears).
2. Select *Parental Control*.
3. Select *USA V-Chip.*
4. Select *Movie Ratings*.

Blocking Movie Ratings

Once you are in the Movie Rating Limit menu, follow these steps to block V-Chip Ratings:

1. Determine the rating you want to block.
2. Press the down arrow button to scroll to the rating you want to change.
3. Press the OK button to change its status to block (the lock icon appears and all ratings above the one you selected change to lock).

V-Chip Exempt Program Block

The *Exempt Prgms.* option lets you decide if programs that the V-Chip recognizes as unrated can be viewed. Unrated TV programs may include news, sports, political, religious, local and weather programs, emergency bulletins, public announcements, and programs without ratings.

Unlocked All unrated programs are available.
Locked All unrated programs are not available.

Note: You must remember to activate V-Chip for rating limits to take effect.

Press the down arrow button to highlight *Exempt Prgms.* Then press the right arrow button to toggle between the lock and unlock icon.

KidPass

The KidPass feature allows parents to set a certain amount of time every day of the week that a child can watch TV. To set KidPass:

1. Select *Parental Control* from the main menu.
2. Select *KidPass* (the *KIDPASS* menu appears with *Current Day* highlighted).

   Note: If you can't select KidPass, you need to set the time. Highlight Go Back, press the right arrow button, then select Time. Highlight Time, then enter the time using the number buttons.

3. Press the right arrow button to select the current day.
4. Press the down arrow button to choose the day of the week.
5. After you've chosen the day of the week, press the right arrow button to select the amount of time: *Free* and *00:30* up to *16:00* (30 minute increments).
6. When you're done setting KidPass, select *Go Back*.
7. Highlight *KidPass active* and press the right arrow button to activate the KidPass settings (box has check mark). The KidPass takes effect immediately.

When the time has expired, the TV shuts off. If you turn on the TV the same day it shut off, the password screen appears (enter the password used for V-Chip).

V-Chip Active

Selecting this option lets you activate and deactivate parental control settings.

1. From the *PARENTAL CONTROL* menu, press the up or down arrow button to highlight *V-Chip active*.
2. Press the right or left arrow button to turn on (box has check mark) or off (box doesn't have check mark) *V-Chip active*.

If you do not activate V-Chip, none of the settings for V-Chip will take effect.

If you forget your password you can reset it. Make sure the TV is off. Simultaneously press and hold VOL< on the TV's front panel and CLEAR on the remote for approximately 5 seconds. Enter a new password the next time you access the PARENTAL CONTROL menu.

Front Panel Lock

Selecting this option lets you lock (disable) or unlock (enable) the TV's front panel. The remote still tunes to any channel. When using this as a Parental Control method, remove access to any remote that is capable of operating the television.

1. From the *PARENTAL CONTROL* menu, press the up or down arrow button to highlight *Lock Fr.* Panel.
2. Press the right or left arrow button to turn on (box has check mark) or off (box doesn't have check mark) front panel lock.

Change Password

Selecting this option lets you simply create a new password at any time. Once you enter a new password from *Change Passwd.* in the *PARENTAL CONTROL* menu it is the password you use until you change it again.



Sound Menu

Treble Increases or decreases the treble.

Bass Increases or decreases the bass.

Balance Press the right arrow button to increase the audio output in the right speaker; press the left arrow button to increase the audio output in the left speaker.

Sound type Press the right arrow button to scroll through the available audio types, which control the way the sound comes through your speakers: *Mono* plays the sound in mono only. Use this setting when receiving broadcasts with weak stereo signals; *Stereo* to split the incoming stereo audio signal into left and right channels; and *Enhanced* for simulated surround sound. Most TV programs and recorded materials have stereo audio. The word *Stereo* appears on the TV when you tune to a program that is broadcast in stereo.

SAP (*Second Audio Program)* Plays the program's audio in a second language, if one is available. The TV displays the word SAP when you tune to a program that is broadcast with SAP information. SAP audio is broadcast in mono. SAP is also used to broadcast a program's audio with descriptions of the video for the visually impaired. Press OK to turn *SAP* on or off.

Auto Vol level (Auto Volume Level) Reduces the annoying blasts in volume during commercial breaks. Eliminates the need to constantly adjust volume control. Press OK to turn *Auto Vol level* on or off.

Audio Output Press the right arrow button to scroll through the available output settings: *Fixed* allows fixed output from the TV's audio output jacks to an external component, such as a surround sound amplifier; and *Variable* allows variable output from the TV's audio output jacks.

Int. Speakers (Internal Speakers) Turns the TV's internal speakers on or off. Turn off the internal speakers if you have an audio receiver or amplifier connected to the TV. Press OK to turn *Int. Speakers* on or off.

Note: Turning the internal speakers off doesn't affect Alert Guard. When an alarm sounds or when the NWR is turned on, Alert Guard will temporarily override this setting.



20F670T, 27V570T, and 27F670T Picture menu



32F670T Picture menu

Picture Menu

The *PICTURE* menu options apply to the video for the main TV and video input selections.

Picture Preset Press the right arrow button to scroll through the available picture preset settings: *Natural*, *Bright*, *Soft*, and *Personal*. Choose the setting that is best for your viewing environment.

Auto Color Turn this option on to automatically correct the color of the picture. This is especially useful for tracking realistic flesh tone colors as you switch from channel to channel.

Color Warmth Press the right arrow button to scroll through the color adjustments: *Cool* for a more blue palette of picture colors; *Normal*; and *Warm* for a more red palette of picture colors.

Brightness Adjusts the brightness of the picture.

Contrast Adjusts the difference between the light and dark areas of the picture.

Color Adjusts the richness of the color.

Sharpness Adjusts the crispness of the edges in the picture.

Note: Sharpness isn't available for component video input channels (CVID2 or CVID3).

Tint Adjusts the balance between the red and green levels.

Note: Tint isn't available for component video input channels (CVID2 or CVID3).

When you change any of these picture settings, the *Picture Preset* changes to *Personal*. Use the left or right arrow button to make adjustments. To return to the *PICTURE* menu, press the up or down arrow button.

Tilt (Available only on model 32F670T) The TV has an extra large picture tube that makes it vulnerable to the effects of the Earth's magnetic field. You may need to adjust the picture tilt.



Setup Menu

Auto Ch. Search (Auto Channel Search) Allows you to choose your signal type and begin an auto channel search.

Signal Type Press the left or right arrow button to select the signal your TV is receiving. Choose *Cable* if you are currently using cable or a cable box for TV signals. Choose *Antenna* if you are currently using an off-air antenna for TV signals.

Start Searches for channels the signal is receiving and stores them in the TV's channel list. Go to page 9 for more information.

List & Labels Edit the channels in the list or choose labels for each channel. For example, if channel 12 is NBC, you can use this feature to label it *NBC* so it appears on-screen as part of the Channel Banner.

To delete a channel from the channel list, highlight *Channel* and use the left or right arrow button to select the channel. Then highlight *In list* and press the OK button. The box should no longer display a check mark.

To add a label to a channel, select the channel in the *Channel* option. Press the down arrow button to highlight *Label*. Press the right arrow button to highlight the first space. Use the up or down arrow button to ascend or descend through the characters. Continue to press the right arrow button to highlight the space and the up or down arrow button to add a character. Press OK when you're finished adding a label.

Closed Caption Many programs are encoded with closed-captioning information, which lets you display the audio portion of a program as text on the TV screen.

Closed captioning is not available on all channels at all times. Only specific programs encoded with closed-captioning information are applicable. When a program is closed captioned, *CC* is displayed in the Channel Banner. Go to Chapter 3 for more information about the Channel Banner. The closed caption options are:

CC Display Lets you choose the way closed captioning information is shown on the screen.

Off No captioning information displayed.

On Captioning information always appears, when available.

Muted=On Displays captioning information, when available, whenever the TV's sound is muted by pressing the MUTE button. The captioning information is not displayed when the sound is not muted.

CC Mode Choose which captioning mode is used for displaying captioning information. If you are unsure of the differences among the modes, you may prefer to leave the closed captioned mode set to CC1, which displays complete text of the program in the primary language in your area.

Auto Tuning Displays a choice list that lets you set up the TV to automatically tune to the correct video input channel when you press a component button (VCR1, VCR2, DVD, SAT•CABLE, etc.) on the remote. Go to Chapter 3 for details about the auto tuning feature.

Language Lets you select your preferred language for the menus, which you should have set in the Initial Setup. Go to page 9 for more information.

Parental Control Menu

The Parental Control menu was explained in Chapter 3. Go to page 24 for more information.



Time Menu

Sleep Timer Lets you set the TV to turn off after a given time. Press the right arrow button to add 15 minutes to the clock (up to four hours).

Time ref. Ch (Time reference Channel) Choose your PBS station to have the TV set the time for you.

Time Time is set if you select a reference channel (see above). If time is not obtained, then enter it manually. If it is 8:25, for example, you must first press the number 0 on the remote, then number 8, then 2 and then 5. Use the OK button to choose between AM and PM.

Wake-Up Timer Lets you set the TV to turn itself on.

Note: If the TV turns on by the wake-up timer and no remote or front panel buttons are pressed for 2 hours , the TV will turn itself off.

Wake-Up Time Lets you set the time you want the TV to turn itself on.

Wake-Up Ch (Wake-Up Channel) Lets you select a specific channel the TV tunes to when the wake-up timer is set.

Alert Guard Menu

The Alert Guard menu was explained in Chapter 3. Go to page 18 for more information.

Troubleshooting

Most problems with your TV can be corrected by consulting the following troubleshooting list.

Note for U.S. customers: If you prefer, we can provide you with the name of an Authorized Service Representative who will visit your home for a fee to install your electronic entertainment system and to instruct you in its operation. For details about this service, call 1-888-206-3359. For additional assistance while using your RCA product, please visit www.rca.com/customersupport.

Alert Guard Problems

NWR channel not clear

- Make sure you have connected the provided Alert Guard antenna to the EXT Alert Guard ANT jack on the back of the TV. Go to page 8 for more information.
- You might be tuned to an NWR channel outside your immediate area. Go to the *NWR CHANNEL* menu to check all NWR channels receiving local area forecasts. Select the channel that sounds most appropriate.
- If the signal's still not clear, you might need to connect an outdoor or amplified antenna to the EXT Alert Guard ANT jack on the back of the TV. For optimal reception, connect an outdoor antenna. Use an amplified antenna if you can't connect an outdoor antenna. Go to page 59 to purchase an amplified antenna.

Not getting local weather information from the NWR channel

- Make sure the NWR channel is set to a local channel.

Message on-screen that READY light is out and NWR channel can't send alerts for My Area

- You might be tuned to an NWR channel outside your immediate area. Go to the *NWR CHANNEL* menu to check all NWR channels receiving forecasts for your local area. If several channels sound equally as good, pick the one with your local forecast.
- You might have set *My Area* to a location where the TV isn't located. For example, you might live in Indiana, but have a cottage in Ottawa County, Michigan. If the TV is in Michigan, you need to set the state of *My Area* to Michigan and the county to Ottawa County. Go to the *Alert Guard* menu and select *Locations* to check *My Area* setting.
- In rare cases, the NWR channel might not serve your area (generally, rural areas). From the *LOCATIONS* menu select the next closest area to you or choose your state and select *All nearby*.

Message on-screen that READY light is out and no weekly test was received

- If you live in an area that generally does not receive good reception and you've tried setting a different NWR channel, you might need to connect an outdoor or amplified antenna to the EXT Alert Guard ANT jack on the back of the TV. For optimal reception, connect an outdoor antenna. Use an amplified antenna if you can't connect an outdoor antenna. Go to page 59 to purchase an amplified antenna.
- If weather conditions are bad for several consecutive days, NOAA might not have been able to broadcast a test. If so, press CLEAR after receiving the message and check in a few days to see if the green READY light is back on. If the problem persists, the message will appear again in 9 days. Failure to fix the problem could result in alerts not being received.

Message on-screen that areas were removed

- NWR channel can't provide information for locations *Nearby 1*, *2*, or *3* (areas set in the *LOCATIONS* menu) if they're outside the reception area.

Message on-screen that I might have missed alerts

- Check the green light. If on, the signal might have been lost momentarily due to interference.
- The NWR channel might be too weak. Press the HEAR VOICE button on the remote. If it's not clear, you need to search for a stronger channel in the *NWR CHANNEL* menu. If you're already receiving the strongest channel, connect an external or amplified antenna to the EXT Alert Guard ANT jack on the back of the TV. For best reception, the external antenna should be located outside your home.

Message on-screen that power was interrupted

- The TV can't receive alerts during a power outage. Press the HEAR VOICE button once power is restored to hear any alerts that might have been issued.

Message seen option not working

- The TV can't display the message when the TV is off. Press the VIEW MESSAGE button to view the alert.

Receiving too many alerts

- Go to the *Alert Guard* menu and select *Locations*. Check all the locations you set. If you've chosen *All of U.S.* or *All nearby*, you might want to select a specific area.
- If all four locations have been set in the *LOCATIONS* menu, consider setting *Nearby 1, 2* and *3* to *No Area*. Highlight the state you set for these areas and then press the left or right arrow button to choose *No Area* (it is listed before *Alabama* and after *St. Lawrence River.*

TV Problems

TV won't turn on

- Press the TV button.
- Make sure the TV is plugged in.
- Check the wall receptacle (or extension cord) to make sure it is "live" by plugging in something else.
- Something might be wrong with your remote control. Press the POWER button on the front of the TV. If the TV turns on, check the remote control solutions on page 35.
- The front panel controls may be locked (disabled). Use the remote control to unlock the front panel controls by selecting the *Lock Fr. Panel* in the *PARENTAL CONTROL* menu and press OK (box won't have check mark).

Buttons don't work

- If you're using the remote control, press the TV button first to make sure the remote is in TV mode.
- The front panel controls may be locked (disabled). Use the remote control to unlock the front panel controls by selecting the *Lock Fr. Panel* in the *PARENTAL CONTROL* menu and press OK (box won't have check mark).
- Unplug the TV for two minutes and then plug it back in. Turn the TV on and try again.

TV turns off unexpectedly

- Sleep timer may have been activated. Go to page 32 for instructions.
- KidPass may have been activated. Go to page 28 for instructions.
- Wake-up timer turned on the TV and no remote or front panel buttons were pressed for two hours.

- Electronic protection circuit may have been activated because of a power surge. Wait 30 seconds and then turn on again. If this happens frequently, the voltage in your house may be abnormally high or low.
- Unplug TV. Wait five minutes. Plug it in again.

TV turns on unexpectedly

- Wake-up timer might have been activated. Go to page 32 for instructions.
- You might have pressed CH+, CH- or OK on the remote accidentally.

Blank screen

- Make sure you have connected the component to the TV correctly.
- Make sure the component connected to the TV's turned on and the TV's tuned to the corresponding video input channel.
- Try another channel.

No sound, picture okay

- Maybe the sound is muted. Try pressing the volume up button to restore sound.
- Make sure the audio cables are fully connected to the AUDIO input jacks.
- If using S-Video or Y, P_B, P_R, remember to also connect the component's left and right audio output jacks to the TV's AUDIO input jacks.
- Make sure the *Int. Speakers* option in the *SOUND* menu is turned on.

Can't select certain channel

- Channel may be blocked or not approved through the V-Chip.
- If using a VCR, check to make sure the TV/VCR button on the VCR is in the correct mode (press the TV/VCR button on your VCR).

Noisy stereo reception

- May be a weak station. Access the *SOUND* menu, highlight *Sound Type* and then choose *Mono*.

No picture/blue screen, no sound but TV is on

- Maybe the signal type is set wrong. Go to page 31 for detailed instructions.
- The channel might be blank — change channels.
- If you're watching your VCR and it's connected with a coaxial cable to the TV ANT jack, tune the TV to channel 3 or 4 (whichever channel is selected on the 3/4 switch on the back of your VCR). Also check to make sure the TV/VCR button on the VCR is in the correct mode (press the TV/VCR button on your VCR).

Sound okay, picture poor

- Check antenna and video connections. Make sure all of the cables are firmly connected to the jacks.
- Try adjusting the sharpness function to improve weak signals. Go to page 30 for more instructions.

Black box appears on the screen

- Closed-captioning might be on. Check *Closed Caption* in the *Setup* menu. Go to page 31 for more instructions.

PASSWORD menu appears

- KidPass option is activated and you try to reset the time.
- You turn the TV on after KidPass shut off the TV.

The Remote Control Doesn't Work

- Something might be between the remote and the remote sensor on the component. Make sure there is a clear path.
- Maybe the remote isn't aimed directly at the component (TV or VCR) that you're trying to operate.
- Maybe remote is not in TV Mode. Press the TV button so remote will control TV.
- Maybe batteries in remote are weak, dead, or installed incorrectly. Put new batteries in the remote. (Note, if you remove the batteries, you may have to reprogram the remote to operate other components.)
- You might need to reset the remote: remove batteries and press the number 1 button for at least 60 seconds. Release the 1 button, replace the batteries, and (if necessary) program the remote again.

Problems with V-Chip/Parental Controls

The rating limits don't work

- You must lock the settings. Go to the *MAIN MENU* (press MENU on your remote), select *Parental Control*, select *V-Chip active*.

I don't remember my password and I want to unlock the TV

- If you forget your password you can reset it. Make sure the TV is off. Simultaneously press and hold VOL< on the TV's front panel and CLEAR on the remote for approximately 5 seconds. Enter a new password the next time you access the *PARENTAL CONTROL* menu.

The V-Chip won't let me watch a program even though it's not rated as violent

- Maybe the movie was given an NR (Not Rated) status. After you block movie ratings, you must set *NR* to *View* separately in order to view movies with an NR rating.

Care and Cleaning

CAUTION: Turn OFF your TV before cleaning.

You can clean the TV as required, using a soft lint-free cloth. Be sure to occasionally dust the ventilation slots in the cabinet to help assure adequate ventilation.

The TV's screen may be cleaned with a soft, lint-free cloth as well. Take care not to scratch or mar the screen. If necessary, you may use a cloth dampened with warm water. Never use strong cleaning agents, such as ammonia-based cleaners, or abrasive powder. These types of cleaners will damage the TV.

While cleaning do not spray liquid directly on the lights on the front of the TV, on the screen, or allow liquid to run down the screen and inside the TV. Also, never place drinks or vases with water on top of the TV. This could increase the risk of fire or shock hazard or damage to the TV.

Caution: Using video games or any external accessory with fixed images for extended periods of time can cause them to be permanently imprinted on the picture tube (or projection TV picture tubes). ALSO, some network/program logos, phone numbers, etc. may cause similar damage. This damage is not covered by your warranty.

Alert Guard Location Codes

If you can't find your location code, call 1-888-NWR-SAME

Alabama Counties

Autauga	001001
Baldwin	001003
Barbour	001005
Bibb	001007
Blount	001009
Bullock	001011
Butler	001013
Calhoun	001015
Chambers	001017
Cherokee	001019
Chilton	001021
Choctaw	001023
Clarke	001025
Clay	001027
Cleburne	001029
Coffee	001031
Colbert	001033
Conecuh	001035
Coosa	001037
Covington	001039
Crenshaw	001041
Cullman	001043
Dale	001045
Dallas	001047
DeKalb	001049
Elmore	001051
Escambia	001053
Etowah	001055
Fayette	001057
Franklin	001059
Geneva	001061
Greene	001063
Hale	001065
Henry	001067
Houston	001069
Jackson	001071
Jefferson	001073
Lamar	001075
Lauderdale	001077
Lawrence	001079
Lee	001081
Limestone	001083
Lowndes	001085
Macon	001087
Madison	001089
Marengo	001091
Marion	001093
Marshall	001095
Mobile	001097
Monroe	001099
Montgomery	001101
Morgan	001103
Perry	001105
Pickens	001107
Pike	001109
Randolph	001111
Russell	001113
St. Clair	001115
Shelby	001117
Sumter	001119
Talladega	001121
Tallapoosa	001123
Tuscaloosa	001125
Walker	001127
Washington	001129
Wilcox	001131
Winston	001133

Alaska

Aleutians East	002013
Aleutians West	002016
Anchorage	002020
Bethel	002050
Bristol Bay	002060
Denali	002068
Dillingham	002070
Fairbanks N. Star	002090
Haines	002100
Juneau	002110
Kenai Peninsula	002122
Ketchikan Gtwy.	002130
Kodiak Island	002150
Lake & Peninsula	002164
Matanuska-Susitna	002170
Nome	002180
North Slope	002185
Northwest Artic	002188
Pr. Wales-Outer Ketch	002201
Sitka	002220
Skagway-Hoonah-Ang	002232
Southeast Fairbanks	002240
Valdez-Cordova	002261
Wade Hampton	002270
Wrangell-Petersburg	002280
Yakutat	002282
Yukon-Koyukuk	002290

American Samoa

Eastern District	060010
Manu'a District	060020
Rose Island	060030
Swains Island	060040
Western District	060050

Arizona Counties

Apache	004001
Cochise	004003
Coconino	004005
Gila	004007
Graham	004009
Greenlee	004011
LaPaz	004012
Maricopa	004013
Mohave	004015
Navajo	004017
Pima	004019
Pinal	004021
Santa Cruz	004023
Yavapai	004025
Yuma	004027

Arkansas Counties

Arkansas	005001
Ashley	005003
Baxter	005005
Benton	005007
Boone	005009
Bradley	005011
Calhoun	005013
Carroll	005015
Chicot	005017
Clark	005019
Clay	005021
Cleburne	005023
Cleveland	005025
Columbia	005027
Conway	005029
Craighead	005031
Crawford	005033
Crittenden	005035
Cross	005037
Dallas	005039
Desha	005041
Drew	005043
Faulkner	005045
Franklin	005047
Fulton	005049
Garland	005051
Grant	005053
Greene	005055
Hempstead	005057
Hot Spring	005059
Howard	005061
Independence	005063
Izard	005065
Jackson	005067
Jefferson	005069
Johnson	005071
Lafayette	005073
Lawrence	005075
Lee	005077
Lincoln	005079
Little River	005081
Logan	005083
Lonoke	005085
Madison	005087
Marion	005089
Miller	005091
Mississippi	005093
Monroe	005095
Montgomery	005097
Nevada	005099
Newton	005101
Ouachita	005103
Perry	005105
Phillips	005107
Pike	005109
Poinsett	005111
Polk	005113
Pope	005115
Prairie	005117
Pulaski	005119
Randolph	005121
St. Francis	005123

If you can't find your location code, call 1-888-NWR-SAME

Saline	005125
Scott	005127
Searcy	005129
Sebastian	005131
Sevier	005133
Sharp	005135
Stone	005137
Union	005139
Van Buren	005141
Washington	005143
White	005145
Woodruff	005147
Yell	005149
California Counties	
Alameda	006001
Alpine	006003
Amador	006005
Butte	006007
Calaveras	006009
Colusa	006011
Contra Costa	006013
Del Norte	006015
El Dorado	006017
Fresno	006019
Glenn	006021
Humboldt	006023
Imperial	006025
Inyo	006027
Kern	006029
Kings	006031
Lake	006033
Lassen	006035
Los Angeles	006037
Madera	006039
Marin	006041
Mariposa	006043
Mendocino	006045
Merced	006047
Modoc	006049
Mono	006051
Monterey	006053
Napa	006055
Nevada	006057
Orange	006059
Placer	006061
Plumas	006063
Riverside	006065
Sacramento	006067
San Benito	006069
San Bernardino	006071
San Diego	006073
San Francisco	006075
San Joaquin	006077
San Luis Obispo	006079
San Mateo	006081
Santa Barbara	006083
Santa Clara	006085
Santa Cruz	006087
Shasta	006089
Sierra	006091
Siskiyou	006093
Solano	006095
Sonoma	006097
Stanislaus	006099
Sutter	006101
Tehama	006103
Trinity	006105
Tulare	006107
Tuolumne	006109
Ventura	006111
Yolo	006113
Yuba	006115
Colorado Counties	
Adams	008001
Alamosa	008003
Arapahoe	008005
Archuleta	008007
Baca	008009
Bent	008011
Boulder	008013
Broomfield	008014
Chaffee	008015
Cheyenne	008017
Clear Creek	008019
Conejos	008021
Costilla	008023
Crowley	008025
Custer	008027
Delta	008029
Denver	008031
Dolores	008033
Douglas	008035
Eagle	008037
Elbert	008039
El Paso	008041
Fremont	008043
Garfield	008045
Gilpin	008047
Grand	008049
Gunnison	008051
Hinsdale	008053
Huerfano	008055
Jackson	008057
Jefferson	008059
Kiowa	008061
Kit Carson	008063
Lake	008065
La Plata	008067
Larimer	008069
Las Animas	008071
Lincoln	008073
Logan	008075
Mesa	008077
Mineral	008079
Moffat	008081
Montezuma	008083
Montrose	008085
Morgan	008087
Otero	008089
Ouray	008091
Park	008093
Phillips	008095
Pitkin	008097
Prowers	008099
Pueblo	008101
Rio Blanco	008103
Rio Grande	008105
Routt	008107
Saguache	008109
San Juan	008111
San Miguel	008113
Sedgwick	008115
Summit	008117
Teller	008119
Washington	008121
Weld	008123
Yuma	008125
Connecticut Counties	
Fairfield	009001
Hartford	009003
Litchfield	009005
Middlesex	009007
New Haven	009009
New London	009011
Tolland	009013
Windham	009015
Delaware Counties	
Kent	010001
New Castle	010003
Sussex	010005
Federated States of Micronesia	
Chuuk	064002
Kosrae	064005
Pohnpei	064040
Yap	064060
Florida Counties	
Alachua	012001
Baker	012003
Bay	012005
Bradford	012007
Brevard	012009
Broward	012011
Calhoun	012013
Charlotte	012015
Citrus	012017
Clay	012019
Collier	012021
Columbia	012023
DeSoto	012027
Dixie	012029
Duval	012031
Escambia	012033
Flagler	012035
Franklin	012037
Gadsden	012039
Gilchrist	012041
Glades	012043
Gulf	012045
Hamilton	012047
Hardee	012049
Hendry	012051
Hernando	012053
Highlands	012055
Hillsborough	012057
Holmes	012059
Indian River	012061
Jackson	012063
Jefferson	012065
Lafayette	012067
Lake	012069
Lee	012071

If you can't find your location code, call 1-888-NWR-SAME

Leon	012073	Bulloch	013031	Gordon	013129	Pickens	013227
Levy	012075	Burke	013033	Grady	013131	Pierce	013229
Liberty	012077	Butts	013035	Greene	013133	Pike	013231
Madison	012079	Calhoun	013037	Gwinnett	013135	Polk	013233
Manatee	012081	Camden	013039	Habersham	013137	Pulaski	013235
Marion	012083	Candler	013043	Hall	013139	Putnam	013237
Martin	012085	Carroll	013045	Hancock	013141	Quitman	013239
Miami-Dade	012086	Catoosa	013047	Haralson	013143	Rabun	013241
Monroe	012087	Charlton	013049	Harris	013145	Randolph	013243
Nassau	012089	Chatham	013051	Hart	013147	Richmond	013245
Okaloosa	012091	Chattahoochee	013053	Heard	013149	Rockdale	013247
Okeechobee	012093	Chattooga	013055	Henry	013151	Schley	013249
Orange	012095	Cherokee	013057	Houston	013153	Screven	013251
Osceola	012097	Clarke	013059	Irwin	013155	Seminole	013253
Palm Beach	012099	Clay	013061	Jackson	013157	Spalding	013255
Pasco	012101	Clayton	013063	Jasper	013159	Stephens	013257
Pinellas	012103	Clinch	013065	Jeff Davis	013161	Stewart	013259
Polk	012105	Cobb	013067	Jefferson	013163	Sumter	013261
Putnam	012107	Coffee	013069	Jenkins	013165	Talbot	013263
St. Johns	012109	Colquitt	013071	Johnson	013167	Taliaferro	013265
St. Lucie	012111	Columbia	013073	Jones	013169	Tattnall	013267
Santa Rosa	012113	Cook	013075	Lamar	013171	Taylor	013269
Sarasota	012115	Coweta	013077	Lanier	013173	Telfair	013271
Seminole	012117	Crawford	013079	Laurens	013175	Terrell	013273
Sumter	012119	Crisp	013081	Lee	013177	Thomas	013275
Suwannee	012121	Dade	013083	Liberty	013179	Tift	013277
Taylor	012123	Dawson	013085	Lincoln	013181	Toombs	013279
Union	012125	Decatur	013087	Long	013183	Towns	013281
Volusia	012127	DeKalb	013089	Lowndes	013185	Treutlen	013283
Wakulla	012129	Dodge	013091	Lumpkin	013187	Troup	013285
Walton	012131	Dooly	013093	McDuffie	013189	Turner	013287
Washington	012133	Dougherty	013095	McIntosh	013191	Twiggs	013289
Georgia Counties		Douglas	013097	Macon	013193	Union	013291
Appling	013001	Early	013099	Madison	013195	Upson	013293
Atkinson	013003	Echols	013101	Marion	013197	Walker	013295
Bacon	013005	Effingham	013103	Meriwether	013199	Walton	013297
Baker	013007	Elbert	013105	Miller	013201	Ware	013299
Baldwin	013009	Emanuel	013107	Mitchell	013205	Warren	013301
Banks	013011	Evans	013109	Monroe	013207	Washington	013303
Barrow	013013	Fannin	013111	Montgomery	013209	Wayne	013305
Bartow	013015	Fayette	013113	Morgan	013211	Webster	013307
Ben Hill	013017	Floyd	013115	Murray	013213	Wheeler	013309
Berrien	013019	Forsyth	013117	Muscogee	013215	White	013311
Bibb	013021	Franklin	013119	Newton	013217	Whitfield	013313
Bleckley	013023	Fulton	013121	Oconee	013219	Wilcox	013315
Brantley	013025	Gilmer	013123	Oglethorpe	013221	Wilkes	013317
Brooks	013027	Glascock	013125	Paulding	013223	Wilkinson	013319
Bryan	013029	Glynn	013127	Peach	013225	Worth	013321

If you can't find your location code, call 1-888-NWR-SAME

Hawaii Counties

Hawaii	015001
Honolulu	015003
Kalawao	015005
Kauai	015007
Maui	015009

Idaho Counties

Ada	016001
Adams	016003
Bannock	016005
Bear Lake	016007
Benewah	016009
Bingham	016011
Blaine	016013
Boise	016015
Bonner	016017
Bonneville	016019
Boundary	016021
Butte	016023
Camas	016025
Canyon	016027
Caribou	016029
Cassia	016031
Clark	016033
Clearwater	016035
Custer	016037
Elmore	016039
Franklin	016041
Fremont	016043
Gem	016045
Gooding	016047
Idaho	016049
Jefferson	016051
Jerome	016053
Kootenai	016055
Latah	016057
Lemhi	016059
Lewis	016061
Lincoln	016063
Madison	016065
Minidoka	016067
Nez Perce	016069
Oneida	016071
Owyhee	016073
Payette	016075
Power	016077
Shoshone	016079
Teton	016081
Twin Falls	016083
Valley	016085
Washington	016087

Illinois Counties

Adams	017001
Alexander	017003
Bond	017005
Boone	017007
Brown	017009
Bureau	017011
Calhoun	017013
Carroll	017015
Cass	017017
Champaign	017019
Christian	017021
Clark	017023
Clay	017025
Clinton	017027
Coles	017029
Cook	017031
Crawford	017033
Cumberland	017035
DeKalb	017037
De Witt	017039
Douglas	017041
DuPage	017043
Edgar	017045
Edwards	017047
Effingham	017049
Fayette	017051
Ford	017053
Franklin	017055
Fulton	017057
Gallatin	017059
Greene	017061
Grundy	017063
Hamilton	017065
Hancock	017067
Hardin	017069
Henderson	017071
Henry	017073
Iroquois	017075
Jackson	017077
Jasper	017079
Jefferson	017081
Jersey	017083
Jo Daviess	017085
Johnson	017087
Kane	017089
Kankakee	017091
Kendall	017093
Knox	017095
Lake	017097
La Salle	017099
Lawrence	017101
Lee	017103
Livingston	017105
Logan	017107
McDonough	017109
McHenry	017111
McLean	017113
Macon	017115
Macoupin	017117
Madison	017119
Marion	017121
Marshall	017123
Mason	017125
Massac	017127
Menard	017129
Mercer	017131
Monroe	017133
Montgomery	017135
Morgan	017137
Moultrie	017139
Ogle	017141
Peoria	017143
Perry	017145
Piatt	017147
Pike	017149
Pope	017151
Pulaski	017153
Putnam	017155
Randolph	017157
Richland	017159
Rock Island	017161
St. Clair	017163
Saline	017165
Sangamon	017167
Schuyler	017169
Scott	017171
Shelby	017173
Stark	017175
Stephenson	017177
Tazewell	017179
Union	017181
Vermilion	017183
Wabash	017185
Warren	017187
Washington	017189
Wayne	017191
White	017193
Whiteside	017195
Will	017197
Williamson	017199
Winnebago	017201
Woodford	017203

Indiana Counties

Adams	018001
Allen	018003
Bartholomew	018005
Benton	018007
Blackford	018009
Boone	018011
Brown	018013
Carroll	018015
Cass	018017
Clark	018019
Clay	018021
Clinton	018023
Crawford	018025
Daviess	018027
Dearborn	018029
Decatur	018031
DeKalb	018033
Delaware	018035
Dubois	018037
Elkhart	018039
Fayette	018041
Floyd	018043
Fountain	018045
Franklin	018047
Fulton	018049
Gibson	018051
Grant	018053
Greene	018055
Hamilton	018057
Hancock	018059
Harrison	018061
Hendricks	018063
Henry	018065
Howard	018067
Huntington	018069
Jackson	018071
Jasper	018073

If you can't find your location code, call 1-888-NWR-SAME

Jay	018075	Warren	018171	Hancock	019081	Van Buren	019177
Jefferson	018077	Warrick	018173	Hardin	019083	Wapello	019179
Jennings	018079	Washington	018175	Harrison	019085	Warren	019181
Johnson	018081	Wayne	018177	Henry	019087	Washington	019183
Knox	018083	Wells	018179	Howard	019089	Wayne	019185
Kosciusko	018085	White	018181	Humboldt	019091	Webster	019187
LaGrange	018087	Whitley	018183	Ida	019093	Winnebago	019189
Lake	018089	**Iowa Counties**		Iowa	019095	Winneshiek	019191
La Porte	018091	Adair	019001	Jackson	019097	Woodbury	019193
Lawrence	018093	Adams	019003	Jasper	019099	Worth	019195
Madison	018095	Allamakee	019005	Jefferson	019101	Wright	019197
Marion	018097	Appanoose	019007	Johnson	019103	**Kansas Counties**	
Marshall	018099	Audubon	019009	Jones	019105	Allen	020001
Martin	018101	Benton	019011	Keokuk	019107	Anderson	020003
Miami	018103	Black Hawk	019013	Kossuth	019109	Atchison	020005
Monroe	018105	Boone	019015	Lee	019111	Barber	020007
Montgomery	018107	Bremer	019017	Linn	019113	Barton	020009
Morgan	018109	Buchanan	019019	Louisa	019115	Bourbon	020011
Newton	018111	Buena Vista	019021	Lucas	019117	Brown	020013
Noble	018113	Butler	019023	Lyon	019119	Butler	020015
Ohio	018115	Calhoun	019025	Madison	019121	Chase	020017
Orange	018117	Carroll	019027	Mahaska	019123	Chautauqua	020019
Owen	018119	Cass	019029	Marion	019125	Cherokee	020021
Parke	018121	Cedar	019031	Marshall	019127	Cheyenne	020023
Perry	018123	Cerro Gordo	019033	Mills	019129	Clark	020025
Pike	018125	Cherokee	019035	Mitchell	019131	Clay	020027
Porter	018127	Chickasaw	019037	Monona	019133	Cloud	020029
Posey	018129	Clarke	019039	Monroe	019135	Coffey	020031
Pulaski	018131	Clay	019041	Montgomery	019137	Comanche	020033
Putnam	018133	Clayton	019043	Muscatine	019139	Cowley	020035
Randolph	018135	Clinton	019045	O'Brien	019141	Crawford	020037
Ripley	018137	Crawford	019047	Osceola	019143	Decatur	020039
Rush	018139	Dallas	019049	Page	019145	Dickinson	020041
St. Joseph	018141	Davis	019051	Palo Alto	019147	Doniphan	020043
Scott	018143	Decatur	019053	Plymouth	019149	Douglas	020045
Shelby	018145	Delaware	019055	Pocahontas	019151	Edwards	020047
Spencer	018147	Des Moines	019057	Polk	019153	Elk	020049
Starke	018149	Dickinson	019059	Pottawattamie	019155	Ellis	020051
Steuben	018151	Dubuque	019061	Poweshiek	019157	Ellsworth	020053
Sullivan	018153	Emmet	019063	Ringgold	019159	Finney	020055
Switzerland	018155	Fayette	019065	Sac	019161	Ford	020057
Tippecanoe	018157	Floyd	019067	Scott	019163	Franklin	020059
Tipton	018159	Franklin	019069	Shelby	019165	Geary	020061
Union	018161	Fremont	019071	Sioux	019167	Gove	020063
Vanderburgh	018163	Greene	019073	Story	019169	Graham	020065
Vermillion	018165	Grundy	019075	Tama	019171	Grant	020067
Vigo	018167	Guthrie	019077	Taylor	019173	Gray	020069
Wabash	018169	Hamilton	019079	Union	019175	Greeley	020071

If you can't find your location code, call 1-888-NWR-SAME

Greenwood	020073	Saline	020169	Clinton	021053	McLean	021149
Hamilton	020075	Scott	020171	Crittenden	021055	Madison	021151
Harper	020077	Sedgwick	020173	Cumberland	021057	Magoffin	021153
Harvey	020079	Seward	020175	Daviess	021059	Marion	021155
Haskell	020081	Shawnee	020177	Edmonson	021061	Marshall	021157
Hodgeman	020083	Sheridan	020179	Elliott	021063	Martin	021159
Jackson	020085	Sherman	020181	Estill	021065	Mason	021161
Jefferson	020087	Smith	020183	Fayette	021067	Meade	021163
Jewell	020089	Stafford	020185	Fleming	021069	Menifee	021165
Johnson	020091	Stanton	020187	Floyd	021071	Mercer	021167
Kearney	020093	Stevens	020189	Franklin	021073	Metcalfe	021169
Kingman	020095	Sumner	020191	Fulton	021075	Monroe	021171
Kiowa	020097	Thomas	020193	Gallatin	021077	Montgomery	021173
Labette	020099	Trego	020195	Garrard	021079	Morgan	021175
Lane	020101	Wabaunsee	020197	Grant	021081	Muhlenberg	021177
Leavenworth	020103	Wallace	020199	Graves	021083	Nelson	021179
Lincoln	020105	Washington	020201	Grayson	021085	Nicholas	021181
Linn	020107	Wichita	020203	Green	021087	Ohio	021183
Logan	020109	Wilson	020205	Greenup	021089	Oldham	021185
Lyon	020111	Woodson	020207	Hancock	021091	Owen	021187
McPherson	020113	Wyandotte	020209	Hardin	021093	Owsley	021189
Marion	020115	**Kentucky Counties**		Harlan	021095	Pendleton	021191
Marshall	020117	Adair	021001	Harrison	021097	Perry	021193
Meade	020119	Allen	021003	Hart	021099	Pike	021195
Miami	020121	Anderson	021005	Henderson	021101	Powell	021197
Mitchell	020123	Ballard	021007	Henry	021103	Pulaski	021199
Montgomery	020125	Barren	021009	Hickman	021105	Robertson	021201
Morris	020127	Bath	021011	Hopkins	021107	Rockcastle	021203
Morton	020129	Bell	021013	Jackson	021109	Rowan	021205
Nemaha	020131	Boone	021015	Jefferson	021111	Russell	021207
Neosho	020133	Bourbon	021017	Jessamine	021113	Scott	021209
Ness	020135	Boyd	021019	Johnson	021115	Shelby	021211
Norton	020137	Boyle	021021	Kenton	021117	Simpson	021213
Osage	020139	Bracken	021023	Knott	021119	Spencer	021215
Osborne	020141	Breathitt	021025	Knox	021121	Taylor	021217
Ottawa	020143	Breckinridge	021027	Larue	021123	Todd	021219
Pawnee	020145	Bullitt	021029	Laurel	021125	Trigg	021221
Phillips	020147	Butler	021031	Lawrence	021127	Trimble	021223
Pottawatomie	020149	Caldwell	021033	Lee	021129	Union	021225
Pratt	020151	Calloway	021035	Leslie	021131	Warren	021227
Rawlins	020153	Campbell	021037	Letcher	021133	Washington	021229
Reno	020155	Carlisle	021039	Lewis	021135	Wayne	021231
Republic	020157	Carroll	021041	Lincoln	021137	Webster	021233
Rice	020159	Carter	021043	Livingston	021139	Whitely	021235
Riley	020161	Casey	021045	Logan	021141	Wolfe	021237
Rooks	020163	Christian	021047	Lyon	021143	Woodford	021239
Rush	020165	Clark	021049	McCracken	021145		
Russell	020167	Clay	021051	McCreary	021147		

If you can't find your location code, call 1-888-NWR-SAME

Louisiana Parishes

Acadia	022001
Allen	022003
Ascension	022005
Assumption	022007
Avoyelles	022009
Beauregard	022011
Bienville	022013
Bossier	022015
Caddo	022017
Calcasieu	022019
Caldwell	022021
Cameron	022023
Catahoula	022025
Claiborne	022027
Concordia	022029
DeSoto	022031
E. Baton Rouge	022033
E. Carroll	022035
E. Feliciana	022037
Evangeline	022039
Franklin	022041
Grant	022043
Iberia	022045
Iberville	022047
Jackson	022049
Jefferson	022051
Jefferson Davis	022053
Lafayette	022055
Lafourche	022057
La Salle	022059
Lincoln	022061
Livingston	022063
Madison	022065
Morehouse	022067
Natchitoches	022069
Orleans	022071
Ouachita	022073
Plaquemines	022075
Pointe Coupee	022077
Rapides	022079
Red River	022081
Richland	022083
Sabine	022085
St. Bernard	022087
St. Charles	022089
St. Helena	022091
St. James	022093
St. John, Baptist	022095
St. Landry	022097
St. Martin	022099
St. Mary	022101
St. Tammany	022103
Tangipahoa	022105
Tensas	022107
Terrebonne	022109
Union	022111
Vermilion	022113
Vernon	022115
Washington	022117
Webster	022119
W. Baton Rouge	022121
W. Carroll	022123
W. Feliciana	022125
Winn	022127

Maine Counties

Androscoggin	023001
Aroostook	023003
Cumberland	023005
Franklin	023007
Hancock	023009
Kennebec	023011
Knox	023013
Lincoln	023015
Oxford	023017
Penobscot	023019
Piscataquis	023021
Sagadahoc	023023
Somerset	023025
Waldo	023027
Washington	023029
York	023031

Marshall Islands

Ailinginae Atoll	068007
Ailinglaplap Atoll	068010
Ailuk Atoll	068030
Arno Atoll	068040
Aur Atoll	068050
Bikar Atoll	068060
Bikini Atoll	068070
Bokak Atoll	068073
Ebon Atoll	068080
Enewetak Atoll	068090
Erikub Atoll	068100
Jabat Island	068110
Jaluit Atoll	068120
Jemo Island	068130
Kili Island	068140
Kwajalein Atoll	068150
Lae Atoll	068160
Lib Island	068170
Likiep Atoll	068180
Majuro Atoll	068190
Maloelap Atoll	068300
Mejit Island	068310
Mili Atoll	068320
Namorik Atoll	068330
Namu Atoll	068340
Rongelap Atoll	068350
Rongrik Atoll	068360
Toke Atoll	068385
Ujae Atoll	068390
Ujelang Atoll	068400
Utrik Atoll	068410
Wotho Atoll	068420
Wotje Atoll	068430

Maryland Cities

City of Baltimore	024510

Maryland Counties

Allegany	024001
Anne Arundel	024003
Baltimore	024005
Calvert	024009
Caroline	024011
Carroll	024013
Cecil	024015
Charles	024017
Dorchester	024019
Frederick	024021
Garrett	024023
Harford	024025
Howard	024027
Kent	024029
Montgomery	024031
Prince George's	024033
Queen Anne's	024035
St. Mary's	024037
Somerset	024039
Talbot	024041
Washington	024043
Wicomico	024045
Worcester	024047

Massachusetts Counties

Barnstable	025001
Berkshire	025003
Bristol	025005
Dukes	025007
Essex	025009
Franklin	025011
Hampden	025013
Hampshire	025015
Middlesex	025017
Nantucket	025019
Norfolk	025021
Plymouth	025023
Suffolk	025025
Worcester	025027

Michigan Counties

Alcona	026001
Alger	026003
Allegan	026005
Alpena	026007
Antrim	026009
Arenac	026011
Baraga	026013
Barry	026015
Bay	026017
Benzie	026019
Berrien	026021
Branch	026023
Calhoun	026025
Cass	026027
Charlevoix	026029
Cheboygan	026031
Chippewa	026033
Clare	026035
Clinton	026037
Crawford	026039
Delta	026041
Dickinson	026043
Eaton	026045
Emmet	026047
Genesee	026049
Gladwin	026051
Gogebic	026053
Grand Traverse	026055
Gratiot	026057
Hillsdale	026059
Houghton	026061
Huron	026063

If you can't find your location code, call 1-888-NWR-SAME

Ingham	026065
Ionia	026067
Iosco	026069
Iron	026071
Isabella	026073
Jackson	026075
Kalamazoo	026077
Kalkaska	026079
Kent	026081
Keweenaw	026083
Lake	026085
Lapeer	026087
Leelanau	026089
Lenawee	026091
Livingston	026093
Luce	026095
Mackinac	026097
Macomb	026099
Manistee	026101
Marquette	026103
Mason	026105
Mecosta	026107
Menominee	026109
Midland	026111
Missaukee	026113
Monroe	026115
Montcalm	026117
Montmorency	026119
Muskegon	026121
Newaygo	026123
Oakland	026125
Oceana	026127
Ogemaw	026129
Ontonagon	026131
Osceola	026133
Oscoda	026135
Otsego	026137
Ottawa	026139
Presque Isle	026141
Roscommon	026143
Saginaw	026145
St. Clair	026147
St. Joseph	026149
Sanilac	026151
Schoolcraft	026153
Shiawassee	026155
Tuscola	026157
Van Buren	026159
Washtenaw	026161
Wayne	026163
Wexford	026165
Minnesota Counties	
Aitkin	027001
Anoka	027003
Becker	027005
Beltrami	027007
Benton	027009
Big Stone	027011
Blue Earth	027013
Brown	027015
Carlton	027017
Carver	027019
Cass	027021
Chippewa	027023
Chisago	027025
Clay	027027
Clearwater	027029
Cook	027031
Cottonwood	027033
Crow Wing	027035
Dakota	027037
Dodge	027039
Douglas	027041
Faribault	027043
Fillmore	027045
Freeborn	027047
Goodhue	027049
Grant	027051
Hennepin	027053
Houston	027055
Hubbard	027057
Isanti	027059
Itasca	027061
Jackson	027063
Kanabec	027065
Kandiyohi	027067
Kittson	027069
Koochiching	027071
Lac qui Parle	027073
Lake	027075
Lake of the Woods	027077
Le Sueur	027079
Lincoln	027081
Lyon	027083
McLeod	027085
Mahnomen	027087
Marshall	027089
Martin	027091
Meeker	027093
Mille Lacs	027095
Morrison	027097
Mower	027099
Murray	027101
Nicollet	027103
Nobles	027105
Norman	027107
Olmsted	027109
Otter Tail	027111
Pennington	027113
Pine	027115
Pipestone	027117
Polk	027119
Pope	027121
Ramsey	027123
Red Lake	027125
Redwood	027127
Renville	027129
Rice	027131
Rock	027133
Roseau	027135
St. Louis	027137
Scott	027139
Sherburne	027141
Sibley	027143
Stearns	027145
Steele	027147
Stevens	027149
Swift	027151
Todd	027153
Traverse	027155
Wabasha	027157
Wadena	027159
Waseca	027161
Washington	027163
Watonwan	027165
Wilkin	027167
Winona	027169
Wright	027171
Yellow Medicine	027173
Mississippi Counties	
Adams	028001
Alcorn	028003
Amite	028005
Attala	028007
Benton	028009
Bolivar	028011
Calhoun	028013
Carroll	028015
Chickasaw	028017
Choctaw	028019
Claiborne	028021
Clarke	028023
Clay	028025
Coahoma	028027
Copiah	028029
Covington	028031
DeSoto	028033
Forrest	028035
Franklin	028037
George	028039
Greene	028041
Grenada	028043
Hancock	028045
Harrison	028047
Hinds	028049
Holmes	028051
Humphreys	028053
Issaquena	028055
Itawamba	028057
Jackson	028059
Jasper	028061
Jefferson	028063
Jefferson Davis	028065
Jones	028067
Kemper	028069
Lafayette	028071
Lamar	028073
Lauderdale	028075
Lawrence	028077
Leake	028079
Lee	028081
Leflore	028083
Lincoln	028085
Lowndes	028087
Madison	028089
Marion	028091
Marshall	028093
Monroe	028095
Montgomery	028097
Neshoba	028099
Newton	028101

If you can't find your location code, call 1-888-NWR-SAME

Noxubee	028103
Oktibbeha	028105
Panola	028107
Pearl River	028109
Perry	028111
Pike	028113
Pontotoc	028115
Prentiss	028117
Quitman	028119
Rankin	028121
Scott	028123
Sharkey	028125
Simpson	028127
Smith	028129
Stone	028131
Sunflower	028133
Tallahatchie	028135
Tate	028137
Tippah	028139
Tishomingo	028141
Tunica	028143
Union	028145
Walthall	028147
Warren	028149
Washington	028151
Wayne	028153
Webster	028155
Wilkinson	028157
Winston	028159
Yalobusha	028161
Yazoo	028163
Missouri Cities	
City of St. Louis	029510
Missouri Counties	
Adair	029001
Andrew	029003
Atchison	029005
Audrain	029007
Barry	029009
Barton	029011
Bates	029013
Benton	029015
Bollinger	029017
Boone	029019
Buchanan	029021
Butler	029023
Caldwell	029025
Callaway	029027
Camden	029029
Cape Girardeau	029031
Carroll	029033
Carter	029035
Cass	029037
Cedar	029039
Chariton	029041
Christian	029043
Clark	029045
Clay	029047
Clinton	029049
Cole	029051
Cooper	029053
Crawford	029055
Dade	029057
Dallas	029059
Daviess	029061
DeKalb	029063
Dent	029065
Douglas	029067
Dunklin	029069
Franklin	029071
Gasconade	029073
Gentry	029075
Greene	029077
Grundy	029079
Harrison	029081
Henry	029083
Hickory	029085
Holt	029087
Howard	029089
Howell	029091
Iron	029093
Jackson	029095
Jasper	029097
Jefferson	029099
Johnson	029101
Knox	029103
Laclede	029105
Lafayette	029107
Lawrence	029109
Lewis	029111
Lincoln	029113
Linn	029115
Livingston	029117
McDonald	029119
Macon	029121
Madison	029123
Maries	029125
Marion	029127
Mercer	029129
Miller	029131
Mississippi	029133
Moniteau	029135
Monroe	029137
Montgomery	029139
Morgan	029141
New Madrid	029143
Newton	029145
Nodaway	029147
Oregon	029149
Osage	029151
Ozark	029153
Pemiscot	029155
Perry	029157
Pettis	029159
Phelps	029161
Pike	029163
Platte	029165
Polk	029167
Pulaski	029169
Putnam	029171
Ralls	029173
Randolph	029175
Ray	029177
Reynolds	029179
Ripley	029181
St. Charles	029183
St. Clair	029185
Ste. Genevieve	029186
St. Francois	029187
St. Louis	029189
Saline	029195
Schuyler	029197
Scotland	029199
Scott	029201
Shannon	029203
Shelby	029205
Stoddard	029207
Stone	029209
Sullivan	029211
Taney	029213
Texas	029215
Vernon	029217
Warren	029219
Washington	029221
Wayne	029223
Webster	029225
Worth	029227
Wright	029229
Montana Counties	
Beaverhead	030001
Big Horn	030003
Blaine	030005
Broadwater	030007
Carbon	030009
Carter	030011
Cascade	030013
Chouteau	030015
Custer	030017
Daniels	030019
Dawson	030021
Deer Lodge	030023
Fallon	030025
Fergus	030027
Flathead	030029
Gallatin	030031
Garfield	030033
Glacier	030035
Golden Valley	030037
Granite	030039
Hill	030041
Jefferson	030043
Judith Basin	030045
Lake	030047
Lewis & Clark	030049
Liberty	030051
Lincoln	030053
McCone	030055
Madison	030057
Meagher	030059
Mineral	030061
Missoula	030063
Musselshell	030065
Park	030067
Petroleum	030069
Phillips	030071
Pondera	030073
Powder River	030075
Powell	030077
Prairie	030079
Ravalli	030081
Richland	030083
Roosevelt	030085

If you can't find your location code, call 1-888-NWR-SAME

Rosebud	030087
Sanders	030089
Sheridan	030091
Silver Bow	030093
Stillwater	030095
Sweet Grass	030097
Teton	030099
Toole	030101
Treasure	030103
Valley	030105
Wheatland	030107
Wibaux	030109
Yellowstone	030111
Nebraska Counties	
Adams	031001
Antelope	031003
Arthur	031005
Banner	031007
Blaine	031009
Boone	031011
Box Butte	031013
Boyd	031015
Brown	031017
Buffalo	031019
Burt	031021
Butler	031023
Cass	031025
Cedar	031027
Chase	031029
Cherry	031031
Cheyenne	031033
Clay	031035
Colfax	031037
Cuming	031039
Custer	031041
Dakota	031043
Dawes	031045
Dawson	031047
Deuel	031049
Dixon	031051
Dodge	031053
Douglas	031055
Dundy	031057
Fillmore	031059
Franklin	031061
Frontier	031063
Furnas	031065
Gage	031067
Garden	031069
Garfield	031071
Gosper	031073
Grant	031075
Greeley	031077
Hall	031079
Hamilton	031081
Harlan	031083
Hayes	031085
Hitchcock	031087
Holt	031089
Hooker	031091
Howard	031093
Jefferson	031095
Johnson	031097
Kearney	031099
Keith	031101
Keya Paha	031103
Kimball	031105
Knox	031107
Lancaster	031109
Lincoln	031111
Logan	031113
Loup	031115
McPherson	031117
Madison	031119
Merrick	031121
Morrill	031123
Nance	031125
Nemaha	031127
Nuckolls	031129
Otoe	031131
Pawnee	031133
Perkins	031135
Phelps	031137
Pierce	031139
Platte	031141
Polk	031143
Red Willow	031145
Richardson	031147
Rock	031149
Saline	031151
Sarpy	031153
Saunders	031155
Scotts Bluff	031157
Seward	031159
Sheridan	031161
Sherman	031163
Sioux	031165
Stanton	031167
Thayer	031169
Thomas	031171
Thurston	031173
Valley	031175
Washington	031177
Wayne	031179
Webster	031181
Wheeler	031183
York	031185
Nevada Cities	
Carson City	032510
Nevada Counties	
Churchill	032001
Clark	032003
Douglas	032005
Elko	032007
Esmeralda	032009
Eureka	032011
Humboldt	032013
Lander	032015
Lincoln	032017
Lyon	032019
Mineral	032021
Nye	032023
Pershing	032027
Storey	032029
Washoe	032031
White Pine	032033
New Hampshire Counties	
Belknap	033001
Carroll	033003
Cheshire	033005
Coos	033007
Grafton	033009
Hillsborough	033011
Merrimack	033013
Rockingham	033015
Strafford	033017
Sullivan	033019
New Jersey Counties	
Atlantic	034001
Bergen	034003
Burlington	034005
Camden	034007
Cape May	034009
Cumberland	034011
Essex	034013
Gloucester	034015
Hudson	034017
Hunterdon	034019
Mercer	034021
Middlesex	034023
Monmouth	034025
Morris	034027
Ocean	034029
Passaic	034031
Salem	034033
Somerset	034035
Sussex	034037
Union	034039
Warren	034041
New Mexico Counties	
Bernalillo	035001
Catron	035003
Chaves	035005
Cibola	035006
Colfax	035007
Curry	035009
De Baca	035011
Doña Ana	035013
Eddy	035015
Grant	035017
Guadalupe	035019
Harding	035021
Hidalgo	035023
Lea	035025
Lincoln	035027
Los Alamos	035028
Luna	035029
McKinley	035031
Mora	035033
Otero	035035
Quay	035037
Rio Arriba	035039
Roosevelt	035041
Sandoval	035043
San Juan	035045
San Miguel	035047
Santa Fe	035049
Sierra	035051
Socorro	035053
Taos	035055
Torrance	035057
Union	035059

If you can't find your location code, call 1-888-NWR-SAME

Valencia	035061
New York Counties	
Albany	036001
Allegany	036003
Bronx	036005
Broome	036007
Cattaraugus	036009
Cayuga	036011
Chautauqua	036013
Chemung	036015
Chenango	036017
Clinton	036019
Columbia	036021
Cortland	036023
Delaware	036025
Dutchess	036027
Erie	036029
Essex	036031
Franklin	036033
Fulton	036035
Genesee	036037
Greene	036039
Hamilton	036041
Herkimer	036043
Jefferson	036045
Kings	036047
Lewis	036049
Livingston	036051
Madison	036053
Monroe	036055
Montgomery	036057
Nassau	036059
New York	036061
Niagara	036063
Oneida	036065
Onondaga	036067
Ontario	036069
Orange	036071
Orleans	036073
Oswego	036075
Otsego	036077
Putnam	036079
Queens	036081
Rensselaer	036083
Richmond	036085
Rockland	036087
St. Lawrence	036089
Saratoga	036091
Schenectady	036093
Schoharie	036095
Schuyler	036097
Seneca	036099
Steuben	036101
Suffolk	036103
Sullivan	036105
Tioga	036107
Tompkins	036109
Ulster	036111
Warren	036113
Washington	036115
Wayne	036117
Westchester	036119
Wyoming	036121
Yates	036123
North Carolina Counties	
Alamance	037001
Alexander	037003
Alleghany	037005
Anson	037007
Ashe	037009
Avery	037011
Beaufort	037013
Bertie	037015
Bladen	037017
Brunswick	037019
Buncombe	037021
Burke	037023
Cabarrus	037025
Caldwell	037027
Camden	037029
Carteret	037031
Caswell	037033
Catawba	037035
Chatham	037037
Cherokee	037039
Chowan	037041
Clay	037043
Cleveland	037045
Columbus	037047
Craven	037049
Cumberland	037051
Currituck	037053
Dare	037055
Davidson	037057
Davie	037059
Duplin	037061
Durham	037063
Edgecombe	037065
Forsyth	037067
Franklin	037069
Gaston	037071
Gates	037073
Graham	037075
Granville	037077
Greene	037079
Guilford	037081
Halifax	037083
Harnett	037085
Haywood	037087
Henderson	037089
Hertford	037091
Hoke	037093
Hyde	037095
Iredell	037097
Jackson	037099
Johnston	037101
Jones	037103
Lee	037105
Lenoir	037107
Lincoln	037109
McDowell	037111
Macon	037113
Madison	037115
Martin	037117
Mecklenburg	037119
Mitchell	037121
Montgomery	037123
Moore	037125
Nash	037127
New Hanover	037129
Northhampton	037131
Onslow	037133
Orange	037135
Pamlico	037137
Pasquotank	037139
Pender	037141
Perquimans	037143
Person	037145
Pitt	037147
Polk	037149
Randolph	037151
Richmond	037153
Robeson	037155
Rockingham	037157
Rowan	037159
Rutherford	037161
Sampson	037163
Scotland	037165
Stanly	037167
Stokes	037169
Surry	037171
Swain	037173
Transylvania	037175
Tyrrell	037177
Union	037179
Vance	037181
Wake	037183
Warren	037185
Washington	037187
Watauga	037189
Wayne	037191
Wilkes	037193
Wilson	037195
Yadkin	037197
Yancey	037199
North Dakota Counties	
Adams	038001
Barnes	038003
Benson	038005
Billings	038007
Bottineau	038009
Bowman	038011
Burke	038013
Burleigh	038015
Cass	038017
Cavalier	038019
Dickey	038021
Divide	038023
Dunn	038025
Eddy	038027
Emmons	038029
Foster	038031
Golden Valley	038033
Grand Forks	038035
Grant	038037
Griggs	038039
Hettinger	038041
Kidder	038043
LaMoure	038045
Logan	038047
McHenry	038049
McIntosh	038051

If you can't find your location code, call 1-888-NWR-SAME

McKenzie	038053
McLean	038055
Mercer	038057
Morton	038059
Mountrail	038061
Nelson	038063
Oliver	038065
Pembina	038067
Pierce	038069
Ramsey	038071
Ransom	038073
Renville	038075
Richland	038077
Rolette	038079
Sargent	038081
Sheridan	038083
Sioux	038085
Slope	038087
Stark	038089
Steele	038091
Stutsman	038093
Towner	038095
Traill	038097
Walsh	038099
Ward	038101
Wells	038103
Williams	038105
Northern Mariana Islands	
Northern Islands	069085
Rota Island	069100
Saipan Island	069110
Tinian Island	069120
Ohio Counties	
Adams	039001
Allen	039003
Ashland	039005
Ashtabula	039007
Athens	039009
Auglaize	039011
Belmont	039013
Brown	039015
Butler	039017
Carroll	039019
Champaign	039021
Clark	039023
Clermont	039025
Clinton	039027
Columbiana	039029
Coshocton	039031
Crawford	039033
Cuyahoga	039035
Darke	039037
Defiance	039039
Delaware	039041
Erie	039043
Fairfield	039045
Fayette	039047
Franklin	039049
Fulton	039051
Gallia	039053
Geauga	039055
Greene	039057
Guernsey	039059
Hamilton	039061
Hancock	039063
Hardin	039065
Harrison	039067
Henry	039069
Highland	039071
Hocking	039073
Holmes	039075
Huron	039077
Jackson	039079
Jefferson	039081
Knox	039083
Lake	039085
Lawrence	039087
Licking	039089
Logan	039091
Lorain	039093
Lucas	039095
Madison	039097
Mahoning	039099
Marion	039101
Medina	039103
Meigs	039105
Mercer	039107
Miami	039109
Monroe	039111
Montgomery	039113
Morgan	039115
Morrow	039117
Muskingum	039119
Noble	039121
Ottawa	039123
Paulding	039125
Perry	039127
Pickaway	039129
Pike	039131
Portage	039133
Preble	039135
Putnam	039137
Richland	039139
Ross	039141
Sandusky	039143
Scioto	039145
Seneca	039147
Shelby	039149
Stark	039151
Summit	039153
Trumbull	039155
Tuscarawas	039157
Union	039159
Van Wert	039161
Vinton	039163
Warren	039165
Washington	039167
Wayne	039169
Williams	039171
Wood	039173
Wyandot	039175
Oklahoma Counties	
Adair	040001
Alfalfa	040003
Atoka	040005
Beaver	040007
Beckham	040009
Blaine	040011
Bryan	040013
Caddo	040015
Canadian	040017
Carter	040019
Cherokee	040021
Choctaw	040023
Cimarron	040025
Cleveland	040027
Coal	040029
Comanche	040031
Cotton	040033
Craig	040035
Creek	040037
Custer	040039
Delaware	040041
Dewey	040043
Ellis	040045
Garfield	040047
Garvin	040049
Grady	040051
Grant	040053
Greer	040055
Harmon	040057
Harper	040059
Haskell	040061
Hughes	040063
Jackson	040065
Jefferson	040067
Johnston	040069
Kay	040071
Kingfisher	040073
Kiowa	040075
Latimer	040077
Le Flore	040079
Lincoln	040081
Logan	040083
Love	040085
McClain	040087
McCurtain	040089
McIntosh	040091
Major	040093
Marshall	040095
Mayes	040097
Murray	040099
Muskogee	040101
Noble	040103
Nowata	040105
Okfuskee	040107
Oklahoma	040109
Okmulgee	040111
Osage	040113
Ottawa	040115
Pawnee	040117
Payne	040119
Pittsburg	040121
Pontotoc	040123
Pottawatomie	040125
Pushmataha	040127
Roger Mills	040129
Rogers	040131
Seminole	040133
Sequoyah	040135
Stephens	040137

If you can't find your location code, call 1-888-NWR-SAME

Texas	040139
Tillman	040141
Tulsa	040143
Wagoner	040145
Washington	040147
Washita	040149
Woods	040151
Woodward	040153
Oregon Counties	
Baker	041001
Benton	041003
Clackamas	041005
Clatsop	041007
Columbia	041009
Coos	041011
Crook	041013
Curry	041015
Deschutes	041017
Douglas	041019
Gilliam	041021
Grant	041023
Harney	041025
Hood River	041027
Jackson	041029
Jefferson	041031
Josephine	041033
Klamath	041035
Lake	041037
Lane	041039
Lincoln	041041
Linn	041043
Malheur	041045
Marion	041047
Morrow	041049
Multnomah	041051
Polk	041053
Sherman	041055
Tillamook	041057
Umatilla	041059
Union	041061
Wallowa	041063
Wasco	041065
Washington	041067
Wheeler	041069
Yamhill	041071

Republic of Palau	
Aimeliik	070002
Airai	070004
Anguar	070010
Hatoboheit	070050
Kayangel	070100
Koror	070150
Melekeok	070212
Ngaraard	070214
Ngarchelong	070218
Ngardmau	070222
Ngatpang	070224
Ngchesar	070226
Ngernmlengui	070227
Ngiwal	070228
Peleliu	070350
Sonsorol	070370
Pennsylvania Counties	
Adams	042001
Allegheny	042003
Armstrong	042005
Beaver	042007
Bedford	042009
Berks	042011
Blair	042013
Bradford	042015
Bucks	042017
Butler	042019
Cambria	042021
Cameron	042023
Carbon	042025
Centre	042027
Chester	042029
Clarion	042031
Clearfield	042033
Clinton	042035
Columbia	042037
Crawford	042039
Cumberland	042041
Dauphin	042043
Delaware	042045
Elk	042047
Erie	042049
Fayette	042051
Forest	042053
Franklin	042055
Fulton	042057
Greene	042059

Huntingdon	042061
Indiana	042063
Jefferson	042065
Juniata	042067
Lackawanna	042069
Lancaster	042071
Lawrence	042073
Lebanon	042075
Lehigh	042077
Luzerne	042079
Lycoming	042081
McKean	042083
Mercer	042085
Mifflin	042087
Monroe	042089
Montgomery	042091
Montour	042093
Northampton	042095
Northumberland	042097
Perry	042099
Philadelphia	042101
Pike	042103
Potter	042105
Schuylkill	042107
Snyder	042109
Somerset	042111
Sullivan	042113
Susquehanna	042115
Tioga	042117
Union	042119
Venango	042121
Warren	042123
Washington	042125
Wayne	042127
Westmoreland	042129
Wyoming	042131
York	042133
Puerto Rico	
Adjuntas	072001
Aguada	072003
Aguadilla	072005
Aguas Buenas	072007
Aibonito	072009
Añasco	072011
Arecibo	072013
Arroyo	072015
Barceloneta	072017
Barranquitas	072019

Bayamón	072021
Cabo Rojo	072023
Caguas	072025
Camuy	072027
Canóvanas	072029
Carolina	072031
Cataño	072033
Cayey	072035
Ceiba	072037
Ciales	072039
Cidra	072041
Coamo	072043
Comerio	072045
Corozal	072047
Culebra	072049
Dorado	072051
Fajardo	072053
Florida	072054
Guánica	072055
Guayama	072057
Guayanilla	072059
Guaynabo	072061
Gurabo	072063
Hatillo	072065
Hormigueros	072067
Humacao	072069
Isabela	072071
Jayuya	072073
Juana Diaz	072075
Juncos	072077
Lajas	072079
Lares	072081
Las Marias	072083
Las Piedras	072085
Loiza	072087
Luquillo	072089
Manati	072091
Maricao	072093
Maunabo	072095
Mayagüez	072097
Moca	072099
Morovis	072101
Naguabo	072103
Naranjito	072105
Orocovis	072107
Patillas	072109
Peñuelas	072111
Ponce	072113

If you can't find your location code, call 1-888-NWR-SAME

Quebradillas	072115
Rincón	072117
Río Grande	072119
Sábana Grande	072121
Salinas	072123
San Germán	072125
San Juan	072127
San Lorenzo	072129
San Sebastián	072131
Santa Isabel	072133
Toa Alta	072135
Toa Baja	072137
Trujillo Alto	072139
Utuado	072141
Vega Alta	072143
Vega Baja	072145
Vieques	072147
Villalba	072149
Yabucoa	072151
Yauco	072153
Rhode Island Counties	
Bristol	044001
Kent	044003
Newport	044005
Providence	044007
Washington	044009
South Carolina Counties	
Abbeville	045001
Aiken	045003
Allendale	045005
Anderson	045007
Bamberg	045009
Barnwell	045011
Beaufort	045013
Berkeley	045015
Calhoun	045017
Charleston	045019
Cherokee	045021
Chester	045023
Chesterfield	045025
Clarendon	045027
Colleton	045029
Darlington	045031
Dillon	045033
Dorchester	045035
Edgefield	045037
Fairfield	045039
Florence	045041
Georgetown	045043
Greenville	045045
Greenwood	045047
Hampton	045049
Horry	045051
Jasper	045053
Kershaw	045055
Lancaster	045057
Laurens	045059
Lee	045061
Lexington	045063
McCormick	045065
Marion	045067
Marlboro	045069
Newberry	045071
Oconee	045073
Orangeburg	045075
Pickens	045077
Richland	045079
Saluda	045081
Spartanburg	045083
Sumter	045085
Union	045087
Williamsburg	045089
York	045091
South Dakota Counties	
Aurora	046003
Beadle	046005
Bennett	046007
Bon Homme	046009
Brookings	046011
Brown	046013
Brule	046015
Buffalo	046017
Butte	046019
Campbell	046021
Charles Mix	046023
Clark	046025
Clay	046027
Codington	046029
Corson	046031
Custer	046033
Davison	046035
Day	046037
Deuel	046039
Dewey	046041
Douglas	046043
Edmunds	046045
Fall River	046047
Faulk	046049
Grant	046051
Gregory	046053
Haakon	046055
Hamlin	046057
Hand	046059
Hanson	046061
Harding	046063
Hughes	046065
Hutchinson	046067
Hyde	046069
Jackson	046071
Jerauld	046073
Jones	046075
Kingsbury	046077
Lake	046079
Lawrence	046081
Lincoln	046083
Lyman	046085
McCook	046087
McPherson	046089
Marshall	046091
Meade	046093
Mellette	046095
Miner	046097
Minnehaha	046099
Moody	046101
Pennington	046103
Perkins	046105
Potter	046107
Roberts	046109
Sanborn	046111
Shannon	046113
Spink	046115
Stanley	046117
Sully	046119
Todd	046121
Tripp	046123
Turner	046125
Union	046127
Walworth	046129
Yankton	046135
Ziebach	046137
Tennessee Counties	
Anderson	047001
Bedford	047003
Benton	047005
Bledsoe	047007
Blount	047009
Bradley	047011
Campbell	047013
Cannon	047015
Carroll	047017
Carter	047019
Cheatham	047021
Chester	047023
Claiborne	047025
Clay	047027
Cocke	047029
Coffee	047031
Crockett	047033
Cumberland	047035
Davidson	047037
Decatur	047039
DeKalb	047041
Dickson	047043
Dyer	047045
Fayette	047047
Fentress	047049
Franklin	047051
Gibson	047053
Giles	047055
Grainger	047057
Greene	047059
Grundy	047061
Hamblen	047063
Hamilton	047065
Hancock	047067
Hardeman	047069
Hardin	047071
Hawkins	047073
Haywood	047075
Henderson	047077
Henry	047079
Hickman	047081
Houston	047083
Humphreys	047085
Jackson	047087
Jefferson	047089
Johnson	047091
Knox	047093

If you can't find your location code, call 1-888-NWR-SAME

Lake	047095	Texas Counties		Concho	048095	Hall	048191
Lauderdale	047097	Anderson	048001	Cooke	048097	Hamilton	048193
Lawrence	047099	Andrews	048003	Coryell	048099	Hansford	048195
Lewis	047101	Angelina	048005	Cottle	048101	Hardeman	048197
Lincoln	047103	Aransas	048007	Crane	048103	Hardin	048199
Loudon	047105	Archer	048009	Crockett	048105	Harris	048201
McMinn	047107	Armstrong	048011	Crosby	048107	Harrison	048203
McNairy	047109	Atascosa	048013	Culberson	048109	Hartley	048205
Macon	047111	Austin	048015	Dallam	048111	Haskell	048207
Madison	047113	Bailey	048017	Dallas	048113	Hays	048209
Marion	047115	Bandera	048019	Dawson	048115	Hemphill	048211
Marshall	047117	Bastrop	048021	Deaf Smith	048117	Henderson	048213
Maury	047119	Baylor	048023	Delta	048119	Hidalgo	048215
Meigs	047121	Bee	048025	Denton	048121	Hill	048217
Monroe	047123	Bell	048027	DeWitt	048123	Hockley	048219
Montgomery	047125	Bexar	048029	Dickens	048125	Hood	048221
Moore	047127	Blanco	048031	Dimmit	048127	Hopkins	048223
Morgan	047129	Borden	048033	Donley	048129	Houston	048225
Obion	047131	Bosque	048035	Duval	048131	Howard	048227
Overton	047133	Bowie	048037	Eastland	048133	Hudspeth	048229
Perry	047135	Brazoria	048039	Ector	048135	Hunt	048231
Pickett	047137	Brazos	048041	Edwards	048137	Hutchison	048233
Polk	047139	Brewster	048043	Ellis	048139	Irion	048235
Putnam	047141	Briscoe	048045	El Paso	048141	Jack	048237
Rhea	047143	Brooks	048047	Erath	048143	Jackson	048239
Roane	047145	Brown	048049	Falls	048145	Jasper	048241
Robertson	047147	Burleson	048051	Fannin	048147	Jeff Davis	048243
Rutherford	047149	Burnet	048053	Fayette	048149	Jefferson	048245
Scott	047151	Caldwell	048055	Fisher	048151	Jim Hogg	048247
Sequatchie	047153	Calhoun	048057	Floyd	048153	Jim Wells	048249
Sevier	047155	Callahan	048059	Foard	048155	Johnson	048251
Shelby	047157	Cameron	048061	Fort Bend	048157	Jones	048253
Smith	047159	Camp	048063	Franklin	048159	Karnes	048255
Stewart	047161	Carson	048065	Freestone	048161	Kaufman	048257
Sullivan	047163	Cass	048067	Frio	048163	Kendall	048259
Sumner	047165	Castro	048069	Gaines	048165	Kenedy	048261
Tipton	047167	Chambers	048071	Galveston	048167	Kent	048263
Trousdale	047169	Cherokee	048073	Garza	048169	Kerr	048265
Unicoi	047171	Childress	048075	Gillespie	048171	Kimble	048267
Union	047173	Clay	048077	Glasscock	048173	King	048269
Van Buren	047175	Cochran	048079	Goliad	048175	Kinney	048271
Warren	047177	Coke	048081	Gonzales	048177	Kleberg	048273
Washington	047179	Coleman	048083	Gray	048179	Knox	048275
Wayne	047181	Collin	048085	Grayson	048181	Lamar	048277
Weakley	047183	Collingsworth	048087	Gregg	048183	Lamb	048279
White	047185	Colorado	048089	Grimes	048185	Lampassas	048281
Wiliamson	047187	Comal	048091	Guadalupe	048187	La Salle	048283
Wilson	047189	Comanche	048093	Hale	048189	Lavaca	048285

If you can't find your location code, call 1-888-NWR-SAME

Lee	048287
Leon	048289
Liberty	048291
Limestone	048293
Lipscomb	048295
Live Oak	048297
Llano	048299
Loving	048301
Lubbock	048303
Lynn	048305
McCulloch	048307
McLennan	048309
McMullen	048311
Madison	048313
Marion	048315
Martin	048317
Mason	048319
Matagorda	048321
Maverick	048323
Medina	048325
Menard	048327
Midland	048329
Milam	048331
Mills	048333
Mitchell	048335
Montague	048337
Montgomery	048339
Moore	048341
Morris	048343
Motley	048345
Nacogdoches	048347
Navarro	048349
Newton	048351
Nolan	048353
Nueces	048355
Ochiltree	048357
Oldham	048359
Orange	048361
Palo Pinto	048363
Panola	048365
Parker	048367
Parmer	048369
Pecos	048371
Polk	048373
Potter	048375
Presidio	048377
Rains	048379
Randall	048381
Reagan	048383
Real	048385
Red River	048387
Reeves	048389
Refugio	048391
Roberts	048393
Robertson	048395
Rockwall	048397
Runnels	048399
Rusk	048401
Sabine	048403
San Augustine	048405
San Jacinto	048407
San Patricio	048409
San Saba	048411
Schleicher	048413
Scurry	048415
Shackelford	048417
Shelby	048419
Sherman	048421
Smith	048423
Somervell	048425
Starr	048427
Stephens	048429
Sterling	048431
Stonewall	048433
Sutton	048435
Swisher	048437
Tarrant	048439
Taylor	048441
Terrell	048443
Terry	048445
Throckmorton	048447
Titus	048449
Tom Green	048451
Travis	048453
Trinity	048455
Tyler	048457
Upshur	048459
Upton	048461
Uvalde	048463
Val Verde	048465
Van Zandt	048467
Victoria	048469
Walker	048471
Waller	048473
Ward	048475
Washington	048477
Webb	048479
Wharton	048481
Wheeler	048483
Wichita	048485
Wilbarger	048487
Willacy	048489
Williamson	048491
Wilson	048493
Winkler	048495
Wise	048497
Wood	048499
Yoakum	048501
Young	048503
Zapata	048505
Zavala	048507
U. S. Minor Outlying Islands	
Baker Island	074050
Howland Island	074100
Jarvis Island	074150
Johnston Atoll	074200
Kingman Reef	074250
Midway Islands	074300
Navassa Island	074350
Palmyra Atoll	074400
Wake Island	074450
Utah Counties	
Beaver	049001
Box Elder	049003
Cache	049005
Carbon	049007
Daggett	049009
Davis	049011
Duchesne	049013
Emery	049015
Garfield	049017
Grand	049019
Iron	049021
Juab	049023
Kane	049025
Millard	049027
Morgan	049029
Piute	049031
Rich	049033
Salt Lake	049035
San Juan	049037
Sanpete	049039
Sevier	049041
Summit	049043
Tooele	049045
Uintah	049047
Utah	049049
Wasatch	049051
Washington	049053
Wayne	049055
Weber	049057
Vermont Counties	
Addison	050001
Bennington	050003
Caledonia	050005
Chittenden	050007
Essex	050009
Franklin	050011
Grand Isle	050013
Lamoille	050015
Orange	050017
Orleans	050019
Rutland	050021
Washington	050023
Windham	050025
Windsor	050027
Virgin Islands	
St. Croix	078010
St. John	078020
St. Thomas	078030
Virginia Cities	
Alexandria	051510
Bedford	051515
Bristol	051520
Buena Vista	051530
Charlottesville	051540
Chesapeake	051550
Colonial Heights	051570
Covington	051580
Danville	051590
Emporia	051595
Fairfax	051600
Falls Church	051610
Franklin	051620
Fredericksburg	051630
Galax	051640
Hampton	051650
Harrisonburg	051660
Hopewell	051670
Lexington	051678
Lynchburg	051680

If you can't find your location code, call 1-888-NWR-SAME

Manassas	051683
Martinsville	051690
Newport News	051700
Norfolk	051710
Norton	051720
Petersburg	051730
Poquoson	051735
Portsmouth	051740
Radford	051750
Richmond	051760
Roanoke	051770
Salem	051775
Staunton	051790
Suffolk	051800
Virginia Beach	051810
Waynesboro	051820
Williamsburg	051830
Winchester	051840
Virginia Counties	
Accomack	051001
Albermarle	051003
Alleghany	051005
Amelia	051007
Amherst	051009
Appomattox	051011
Arlington	051013
Augusta	051015
Bath	051017
Bedford	051019
Bland	051021
Botetourt	051023
Brunswick	051025
Buchanan	051027
Buckingham	051029
Campbell	051031
Caroline	051033
Carroll	051035
Charles City	051036
Charlotte	051037
Chesterfield	051041
Clarke	051043
Craig	051045
Culpeper	051047
Cumberland	051049
Dickenson	051051
Dinwiddie	051053
Essex	051057
Fairfax	051059
Fauquier	051061
Floyd	051063
Fluvanna	051065
Franklin	051067
Frederick	051069
Giles	051071
Gloucester	051073
Goochland	051075
Grayson	051077
Greene	051079
Greensville	051081
Halifax	051083
Hanover	051085
Henrico	051087
Henry	051089
Highland	051091
Isle of Wight	051093
James City	051095
King and Queen	051097
King George	051099
King William	051101
Lancaster	051103
Lee	051105
Loudoun	051107
Louisa	051109
Lunenburg	051111
Madison	051113
Manassas Park	051685
Mathews	051115
Mecklenburg	051117
Middlesex	051119
Montgomery	051121
Nelson	051125
New Kent	051127
Northampton	051131
Northumberland	051133
Nottoway	051135
Orange	051137
Page	051139
Patrick	051141
Pittsylvania	051143
Powhatan	051145
Prince Edward	051147
Prince George	051149
Prince William	051153
Pulaski	051155
Rappahannock	051157
Richmond	051159
Roanoke	051161
Rockbridge	051163
Rockingham	051165
Russell	051167
Scott	051169
Shenandoah	051171
Smyth	051173
Southampton	051175
Spotsylvania	051177
Stafford	051179
Surry	051181
Sussex	051183
Tazewell	051185
Warren	051187
Washington	051191
Westmoreland	051193
Wise	051195
Wythe	051197
York	051199
Washington Counties	
Adams	053001
Asotin	053003
Benton	053005
Chelan	053007
Clallam	053009
Clark	053011
Columbia	053013
Cowlitz	053015
Douglas	053017
Ferry	053019
Franklin	053021
Garfield	053023
Grant	053025
Grays Harbor	053027
Island	053029
Jefferson	053031
King	053033
Kitsap	053035
Kittitas	053037
Klickitat	053039
Lewis	053041
Lincoln	053043
Mason	053045
Okanogan	053047
Pacific	053049
Pend Oreille	053051
Pierce	053053
San Juan	053055
Skagit	053057
Skamania	053059
Snohomish	053061
Spokane	053063
Stevens	053065
Thurston	053067
Wahkiakum	053069
Walla Walla	053071
Whatcom	053073
Whitman	053075
Yakima	053077
West Virginia Counties	
Barbour	054001
Berkeley	054003
Boone	054005
Braxton	054007
Brooke	054009
Cabell	054011
Calhoun	054013
Clay	054015
Doddridge	054017
Fayette	054019
Gilmer	054021
Grant	054023
Greenbrier	054025
Hampshire	054027
Hancock	054029
Hardy	054031
Harrison	054033
Jackson	054035
Jefferson	054037
Kanawha	054039
Lewis	054041
Lincoln	054043
Logan	054045
McDowell	054047
Marion	054049
Marshall	054051
Mason	054053
Mercer	054055
Mineral	054057
Mingo	054059
Monongalia	054061
Monroe	054063
Morgan	054065
Nicholas	054067
Ohio	054069
Pendleton	054071

If you can't find your location code, call 1-888-NWR-SAME

Pleasants	054073
Pocahontas	054075
Preston	054077
Putnam	054079
Raleigh	054081
Randolph	054083
Ritchie	054085
Roane	054087
Summers	054089
Taylor	054091
Tucker	054093
Tyler	054095
Upshur	054097
Wayne	054099
Webster	054101
Wetzel	054103
Wirt	054105
Wood	054107
Wyoming	054109

Wisconsin Counties

Adams	055001
Ashland	055003
Barron	055005
Bayfield	055007
Brown	055009
Buffalo	055011
Burnett	055013
Calumet	055015
Chippewa	055017
Clark	055019
Columbia	055021
Crawford	055023
Dane	055025
Dodge	055027
Door	055029
Douglas	055031
Dunn	055033
Eau Claire	055035
Florence	055037
Fond du Lac	055039
Forest	055041
Grant	055043
Green	055045
Green Lake	055047
Iowa	055049
Iron	055051
Jackson	055053
Jefferson	055055
Juneau	055057
Kenosha	055059
Kewaunee	055061
La Crosse	055063
Lafayette	055065
Langlade	055067
Lincoln	055069
Manitowoc	055071
Marathon	055073
Marinette	055075
Marquette	055077
Menominee	055078
Milwaukee	055079
Monroe	055081
Oconto	055083
Oneida	055085
Outagamie	055087
Ozaukee	055089
Pepin	055091
Pierce	055093
Polk	055095
Portage	055097
Price	055099
Racine	055101
Richland	055103
Rock	055105
Rusk	055107
St. Croix	055109
Sauk	055111
Sawyer	055113
Shawano	055115
Sheboygan	055117
Taylor	055119
Trempealeau	055121
Vernon	055123
Vilas	055125
Walworth	055127
Washburn	055129
Washington	055131
Waukesha	055133
Waupaca	055135
Waushara	055137
Winnebago	055139
Wood	055141

Wyoming Counties

Albany	056001
Big Horn	056003
Campbell	056005
Carbon	056007
Converse	056009
Crook	056011
Fremont	056013
Goshen	056015
Hot Springs	056017
Johnson	056019
Laramie	056021
Lincoln	056023
Natrona	056025
Niobrara	056027
Park	056029
Platte	056031
Sheridan	056033
Sublette	056035
Sweetwater	056037
Teton	056039
Uinta	056041
Washakie	056043
Weston	056045

Marine Areas

Pacific U.S. West Coast	057000
Pacific Alaska Coast	058000
Central Pacific Hawaii	059000
S. Cntrl Pacific Am. Samoa	061000
W. Pacific Marina Islands	065000
Atlantic Coast Canada - NC	073000
Atlantic NC-FL + Caribbean	075000
Gulf of Mexico FL - Mexico	077000
Lake Superior	091000
Lake Michigan	092000
Lake Huron	093000
Lake St. Clair	094000
Lake Erie	096000
Lake Ontario	097000
St. Lawrence River	098000

Limited Warranty (for models 20F670T, 27F670T and 32F670T)

What your warranty covers:

- Defects in material or workmanship.

For how long after your purchase:

- One year from date of purchase for labor charges.
- One year from date of purchase for parts.
- Two years from date of purchase for picture tube.

The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm whichever comes first.

What we will do:

- Pay any Authorized RCA Television Service Center the labor charges to repair your television.
- Pay any Authorized RCA Television Service Center for the new or, at our option, rebuilt replacement parts and picture tube required to repair your television.

How you get service:

- For 20" screen size: Take your RCA television to any Authorized RCA Television Service Center and pickup when repairs are complete.
- For screen sizes larger than 20": Request home or pick up, repair and return service from any Authorized RCA Television Service Center, provided that your television is located within the geographic territory covered by an Authorized RCA Television Service Center. If not, you must take your television to the Service Center location at your own expense, or pay for the cost the Service Center may charge to transport your television to and from your home.
- To identify your nearest Authorized RCA Service Center, ask your dealer, visit www.rca.com, look in the Yellow Pages, or call 1-800-336-1900.
- Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period must be presented to obtain warranty service. For rental firms, proof of first rental is also required.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual describes how to install, adjust, and operate your product. Any additional information should be obtained from your dealer.)
- Installation and related adjustments.
- Signal reception problems not caused by your television.
- Damage from misuse or neglect.
- Batteries.
- Customer replacement fuses.
- Damage from images burnt onto the screen.
- A television that has been modified or incorporated into other products or is used for institutional or other commercial purposes.
- Acts of nature, such as but not limited to lightning damage.
- A television purchased or serviced outside the U.S.A.

Product Registration:

- Please complete and mail the Product Registration Card packed with your TV or register on-line at www.rca.com/productregistration. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

Limitation of Warranty:

- **THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY THOMSON INC., ITS AGENTS OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.**
- **REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. THOMSON INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.**

How state law relates to this warranty:

- Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.
- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

If you purchased your product outside the United States:

- This warranty does not apply. Contact your dealer for warranty information.

Service calls which do not involve defective materials or workmanship are not covered by this warranty. Costs of such service calls are the sole responsibility of the purchaser.

Limited Warranty (for model 27V570T)

What your warranty covers:

- Defects in material or workmanship.

For how long after your purchase:

- 90 days from date of purchase for labor charges.
- One year from date of purchase for parts.
- Two years from date of purchase for the picture tubes.

The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.

What we will do:

- Pay any Authorized RCA Television Service Center the labor charges to repair your television.
- Pay any Authorized RCA Television Service Center for the new or, at our option, rebuilt replacement parts and picture tube required to repair your television.

How you get service:

- For 20" screen size: Take your RCA television to any Authorized RCA Television Service Center and pickup when repairs are complete.
- For screen sizes larger than 20": Request home or pick up, repair and return service from any Authorized RCA Television Service Center, provided that your television is located within the geographic territory covered by an Authorized RCA Television Service Center. If not, you must take your television to the Service Center location at your own expense, or pay for the cost the Service Center may charge to transport your television to and from your home.
- To identify your nearest Authorized RCA Service Center, ask your dealer, visit www.rca.com, look in the Yellow Pages, or call 1-800-336-1900.
- Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the product is within the warranty period must be presented to obtain warranty service. For rental firms, proof of first rental is also required.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual describes how to install, adjust, and operate your product. Any additional information should be obtained from your dealer.)
- Installation and related adjustments.
- Signal reception problems not caused by your television.
- Damage from misuse or neglect.
- Batteries.
- Customer replacement fuses.
- Damage from images burnt onto the screen.
- A television that has been modified or incorporated into other products or is used for institutional or other commercial purposes.
- Acts of nature, such as but not limited to lightning damage.
- A television purchased or serviced outside the U.S.A.

Product Registration:

- Please complete and mail the Product Registration Card packed with your TV or register on-line at www.rca.com/productregistration. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

Limitation of Warranty:

- **THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY THOMSON INC., ITS AGENTS OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.**
- **REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. THOMSON INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.**

How state law relates to this warranty:

- Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.
- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

If you purchased your product outside the United States:

- This warranty does not apply. Contact your dealer for warranty information.

Service calls which do not involve defective materials or workmanship are not covered by this warranty. Costs of such service calls are the sole responsibility of the purchaser.

RCR160THM1

Remote Control This is the remote control that came packed with your TV. Replacements or spares can be ordered as needed.



VH47

2-way Signal Splitter helps you connect to a second TV or VCR.



ANT200

Amplified VHF/UHF/FM Antenna allows you to easily switch from the antenna signal to cable or satellite easily without disconnecting antenna.



DT6DC (6-ft)

DT12DC (12-ft)

Component Video Cables Triple cable used to connect a video source with Y, Pr, Pb jacks to the TV.



VH81 (3-ft)

VH82 (6-ft)

Screw-on Cable attaches to the round antenna connectors (called 75-ohm F-type) on the back of your VCR or TV. The ends screw onto the connectors for a secure connection.

VH83

Standard Audio/Video cable with RCA-type phono plugs.

Description	Part No.	Price
Screw-on antenna cable (3-ft)	VH81	$3.95
Screw-on antenna cable (6-ft)	VH82	$4.95
Push-on antenna cable (6-ft)	VH89	$5.95
Monaural VCR Dubbing Cable (6-ft)	VH83	$5.95
Stereo VCR Dubbing Cable (6-ft)	VH84	$9.95
S-Video Cable (6-ft)	VH976	$7.95
S-Video Cable (12-ft)	VH913	$14.95
2-way Signal Splitter	VH47	$3.95
Amplified Antenna	ANT200	$49.95
Remote Control (RCR160THM1)	258449	$25.45
Audio•Video Adapter	228449	$4.45
Surge Protector	SCTV4000C	$49.95
Component Video Cables (6-ft)	DT6DC	$24.95
Component Video Cables (12-ft)	DT12DC	$34.95

Prices are subject to change without notice.

VH913

S-Video Cable has multi-pin connectors on each end for connecting S-Video components to your TV.



SCTV4000C

Surge Protector provides eight outlets, coaxial and telephone line protection. Audible alarm for surge failure.

HOW TO ORDER

ON-LINE: Accessories may also be purchased at www.rca.com/accessories (subject to availability).
BY PHONE: To place your order by phone, have your Visa, MasterCard or Discover Card ready and call **1-800-338-0376**. Use this number only to place an order for accessory items listed on this page.

All accessories are subject to availability.
Where applicable, we will ship a superseding model.

Televison Receiver

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

FCC Declaration of Conformity

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: RCA

Model(s): 20F670T, 27V570T, 27F670T, 32F670T

Equipment Classification: Radio receiver subject to part 15 of the FCC regulations

Responsible Party: Thomson Inc.
10330 N. Meridian St.
Indianapolis, IN 46290
Telephone 1-580-634-0151

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Visit the RCA web site at www.rca.com

Please do not send any products to the Indianapolis address listed in this manual or on the carton. This will only add delays in service for your product.

Thomson Inc.
10330 North Meridian Street
Indianapolis, IN 46290

©2003 Thomson Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
TOCOM 16161830

THOMSON
THOMSON